



A=TO FUEL PUMP

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1277	828361A 2	OIL TANK	1		
2		828475A 1	CAP ASSEMBLY	1		
3	25	26318	O RING	1		
4		828793	DIPSTICK	1		
5	11	11316 1	NUT	1		
6		19299A 1	VENT ASSEMBLY	1		
7	21	64871	VALVE	1		
8		828720 1	BRACKET	1		
9		99160	BOOT	1		
10	10	40106 20	SCREW (M6X20)	2		
11	25	825380	GROMMET	1		
12	23	828350	BUSHING	1		
13	12	817274	WASHER	1		
14	10	818934 35	SCREW (M8X35)	1		
15	87	12886A 6	SWITCH ASSEMBLY	1		
16	10	58376	SCREW (.164-18 X .375)	1		
17	12	72761	WASHER	1		
18	43	43020 4	DRIVEN GEAR	1		
19	25	62705	O-RING	2		
20		17335A 3	ADAPTOR ASSEMBLY	1		
21	23	17597	BUSHING	1		
22	23	17596	JOURNAL BUSHING	1		
23		42959A 2	OIL PUMP	1		
24	10	821045 40	SCREW (M5 X 40)	2		
25	32	823813 29	TUBING (6 IN.)	1		
26	32	823814 55	TUBING (11 IN.)	1		1
27	54	816311	STA-STRAP	AR	(8 IN.)	11
27		69355	STA-STRAP	AR	(5-1/2 IN.)	11
-	27	43004A90	GASKET SET	1		