



4657

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	19	45307	PLUG, (Yellow)	1		
2		812777T 1	COVER ASSEMBLY	1		
3	11	42979	NUT, (M16)	1		
4	12	68229	WASHER	1		
5	261	878226T10	FLYWHEEL ASSEMBLY	1	(Electric-Oil Injection)	
5	261	878226T16	FLYWHEEL ASSEMBLY	1	(Electric-Non Oil Injection)	
6	261	878226T 8	FLYWHEEL ASSEMBLY	1	(Manual)	
7	398	832075A21	STATOR ASSEMBLY	1	(Electric)	
7	398	832074A11	STATOR ASSEMBLY	1	(Manual)	
8	10	40139 25	SCREW, (M5 x 25)	4		
9		854512T	TRIGGER	1		
10		56762	CABLE TIE, (4.00 Inches)	3		
11		93254	SWIVEL BASE	1		
12		93421	SWIVEL BALL	1		
13	50	66015T 1	STARTER MOTOR	1		
13	50	893891T	STARTER MOTOR	1		
14		56703	COLLAR	2		
15	17	68402	PIN, (.250 x 1.13)	2		
16	84	93388A 1	CABLE ASSEMBLY, Black	1		
17	10	69035	SCREW AND LOCKWASHER, (.250)	1		
18	84	93388A 8	CABLE ASSEMBLY, (Black)	1		
19	13	26392	LOCKWASHER, (.250)	1		
20	11	64015	NUT, (.250-20)	1		
21	37	827282 2	DECAL, Warning, High Voltage	1	(Electric)	
22		13541	PLUG, Male	2	(Manual)	
23	37	881865	DECAL, Caution-Start in Gear	1	(Start In Gear) (Electric)	