



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		55156A 5	FUEL PUMP ASSEMBLY	1		
2	21	30430A 3	CHECK VALVE ASSEMBLY	2		
3		55278A 1	DIAPHRAGM KIT	1		4
4			GASKET, CHECK VALVE TO	2		4
5			GASKET, FUEL PUMP	2		4
6		23004	RETAINER, CHECK VALVE	1		
7	10	20037	SCREW, RETAINER TO HOUSII	2		
8	10	35581	SCREW, PUMP MOUNTING (1 5/	3		
9	22	32802	PLUG, PIPE - FUEL PUMP	1		
10	32	60814A 1	FUEL LINE ASSEMBLY, FUEL PUI	1		
11		58907	HOUSING, FUEL FILTER AND CO	1		
12	10	37558	SCREW, FILTER HOUSING TO FI	2		
13	12	34437	WASHER, FUEL FILTER HOUSIN	2		
14	27	25851	GASKET, FILTER COVER (BOTTC	1		4
15	1399	3938	ELEMENT, FUEL FILTER	1		
16	27	25849	GASKET, FILTER COVER (TOP)	1		4
17	1399	4791	COVER, FUEL FILTER	1		
18	10	25822	SCREW, FILTER COVER FASTEN	1		
19	27	25848	GASKET, FILTER COVER FASTEN	1		4
20	32	38527	FUEL LINE, FILTER COVER TO U	1		
21	22	29085	ELBOW, (450) - UPPER CARBURI	1		
21A	22	36567	ELBOW, LOWER CARBURETOR	1		
22	32	62989A 1	FUEL LINE, FILTER COVER TO LI	1		
23	32	55829	FUEL LINE ASSEMBLY, FUEL PUI	1		
24	22	30177	NUT, FUEL LINE	2		
25	22	30175	SLEEVE, FUEL LINE	2		
26	22	30468	CONNECTOR, FUEL LINE	2		
27		30186	ADAPTOR, CHECK UNIT (FUEL LI	1		
28		30187	STEM, CHECK UNIT ADAPTOR	1		
29	25	20415	"O" RING, ADAPTOR STEM	1		4
30	24	30189	SPRING, ADAPTOR STEM	1		
31		30188	CUP WASHER, ADAPTOR	1		
32	10	24644	SCREW, ADAPTOR TO FRONT S	2		
33	11	46887	NUT, ADAPTOR FASTENING SCF	2		