



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		58908	BRACKET, ANCHOR - CONTROL	1		
2		60283A 1	LINK ASSEMBLY, SHIFT SHAFT A	1		
3	24	20099	SPRING, LINK TO ANCHOR BRAC	1		
4		37896	GUIDE BLOCK, LINK	1		
5		52100	WEAR PLATE, NYLON - LINK	1		
6		38279	LATCH, LINK TO ANCHOR BRAC	1		
7	12	21631	WASHER, LINK LATCH	1		
8	11	20664	NUT, LINK ATTACHING	2		
9		60304A 2	SHIFT SHAFT ASSEMBLY, UPPEF	1		
9		60304A 1	SHIFT SHAFT ASSEMBLY, UPPEF	1		
10		55692	COUPLING, SHIFT SHAFT	1		
11	13	29720	WASHER, WAVE - SHIFT SHAFT	1		
12	23	26600	BUSHING, NYLON - SHIFT SHAFT	1		
13	12	24664	WASHER, LINK (SHIFT SHAFT EP	1		
14		39519	CUP, RETAINER - ANCHOR BRAC	1		
15		39618	LEVER, NYLON - SHIFT CABLE LI	1		
16	17	47175	PIN, LOCKING LEVER AND COVE	3		
17		39536	LINK, LOCKING LEVER TO COVE	1		
18		39667	COVER, NYLON - SHIFT CABLE	1		
19	10	53167	SCREW, ANCHOR BRACKET TO	3		
20	27	60317	GASKET, POWERHEAD TO EXHA	1		4
21		58909A 4	EXHAUST PLATE ASSEMBLY	1		
22	16	20985	STUD, EXHAUST PLATE TO DF	1		
23	16	48769	STUD, EXHAUST PLATE TO DF	1		
24	26	38452	SEAL, WATER INLET TUBE	1		4
25	12	38453	WASHER, NYLON - WATER INL	1		
26		38500	RETAINER, WATER INLET TUE	1		
27	10	34439	SCREW, RETAINER TO EXHAU	1		
28		60307	SEAL, EXHAUST PLATE	1		
29		60306	STRIP, RETAINING - EXHAUST	1		
30	10	30663	SCREW, RETAINING STRIP TO	3		
31		63007	MOUNT, RUBBER - EXHAUST PL	1		
32		49651A 1	GROUND STRAP ASSY, EXHAUS	1		
33	12	20346	WASHER, RUBBER MOUNT ATT.	2		
34	11	20361	NUT, RUBBER MOUNT TO EXHA	2		
35	10	24234	SCREW, EXHAUST PLATE TO CY	3		
36	27	38501	GASKET, ADAPTOR PLATE TO D	1		4
37		58911	EXHAUST TUBE, ADAPTOR	1		
38	27	60280	GASKET, EXHAUST TUBE TO EX	1		4
39	10	49668	SCREW, EXHAUST TUBE TO EX	3		