



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	450	4393A 2	CRANKSHAFT ASSEMBLY	1	
2	30	64424	BEARING, BALL - LOWER AND	2	
3	15	22369A 1	SHIM, LOWER BEARING TO CRA	AR	
4		60834A 3	CARRIER ASSEMBLY, "O" RING	1	
5		64254	"O" RING, CARRIER	1	2,3,4
6	542	4846A 7	MAIN BEARING ASSEMBLY (VAL)	2	
7	17	20032	DOWEL PIN, MAIN BEARING	4	
8	17	60282	DOWEL PIN (STEPPED)	2	
9	17	65855	DOWEL PIN, REED STOP	16	
10	34	66051A 1	REED SET, MATCHED - MAIN B	2	
11	34	65946	REED STOP	8	
12	10	53481	SCREW, REED STOP MOUNTIN	8	
13	11	20110	NUT, REED STOP MOUNTING	8	
14	10	45775	SCREW, MAIN BEARING CLAM	4	
15	11	45774	NUT, MAIN BEARING SCREW	4	
16		26113	RACE, OUTER (PAIR)	2	
17	53	26933	RING, SNAP - OUTER RACE	2	
18	29	52168	BEARING, NEEDLE	112	
19	745	5218A 3	PISTON AND PISTON PIN ASSE	3	
20	40	52035	LOCK RING, PISTON PIN	6	
21	39	45155A12	RING, PISTON	1	
22	622	4850A 3	CONNECTING ROD AND CAP AS	3	
23	10	54803	SCREW, CAP TO CONNECTING	6	
24	11	49091	NUT, CONNECTING ROD SCRE	6	
25	31	62596A 1	BEARING ASSEMBLY, CRANKP	3	
26	29	47270	BARING, NEEDLE - PISTON PIN	87	
27	12	47247	WASHER, NEEDLE LOCATING	6	
--	745	5303A 2	PISTON AND PISTON PIN ASSE	3	OVERSIZE PISTON AND RING
--	39	45204A12	RING, PISTON (.015)	1	OVERSIZE PISTON AND RING