



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		58908	BRACKET, ANCHOR - CONTROL	1	
2		60283A 1	LINK ASSEMBLY, SHIFT SHAFT A	1	
3	24	20099	SPRING, LINK TO ANCHOR BRAC	1	
4		37896	GUIDE BLOCK, LINK	1	
5		52100	WEAR PLATE, NYLON - LINK	1	
6		38279	LATCH, LINK TO ANCHOR BRAC	1	
7	12	21631	WASHER, LINK LATCH	1	
8	11	20664	NUT, LINK ATTACHING	2	
9		60304A 2	SHIFT SHAFT ASSEMBLY, UPPE	1	UNITED STATES 4259239 AND I
9		60304A 1	SHIFT SHAFT, ASSEMBLY, UPPE	1	UNITED STATES 4259239 AND I
10		55692	COUPLING, SHIFT SHAFT	1	UNITED STATES 4259239 AND I
9		69785A 3	SHIFT SHAFT ASSEMBLY, UPPE	1	UNITED STATES 4259240 AND I
9		69785A 4	SHIFT SHAFT ASSEMBLY, UPPE	1	UNITED STATES 4259240 AND I
11	13	29720	WASHER, WAVE - SHIFT SHAFT	1	
12	23	26600	BUSHING, NYLON - SHIFT SHAF	1	
13	12	24664	WASHER, LINK (SHIFT SHAFT EP	1	
14		39519	CUP, RETAINER - ANCHOR BRAC	1	
15		39618	LEVER, NYLON - SHIFT CABLE LI	1	
16	17	47175	PIN, LOCKING LEVER AND COVE	3	
17		39536	LINK, LOCKING LEVER TO COVE	1	UNITED STATES 3807832 AND I
17		65799	LINK, LOCKING LEVER TO COVE	1	UNITED STATES 3807833 AND I
18		39667	COVER, NYLON - SHIFT CABLE	1	
19	10	69101	SCREW, ANCHOR BRACKET TO	3	
20	27	60317	GASKET, POWERHEAD TO EXHA	1	2,3,4
21		64965A 4	EXHAUST PLATE ASSEMBLY	1	UNITED STATES 3660087 AND I
21		65354A 4	EXHAUST PLATE ASSEMBLY	1	UNITED STATES 3660088 THRL
21		72268A 1	EXHAUST PLATE ASSEMBLY	1	UNITED STATES 4136685 AND I
21A	23	27132	BUSHING, NYLON - EXHAUST P	1	UNITED STATES 4136685 AND I
22	16	69058	STUD, EXHAUST PLATE TO DF	1	
23	16	68166	STUD, EXHAUST PLATE TO DF	1	
24		73156	SEAL, WATER INLET TUBE	1	2,3,4
25	12	38453	WASHER, NYLON - WATER INL	1	
26		38500	RETAINER, WATER INLET TUE	1	
27	10	69069	SCREW, RETAINER TO EXHAU	1	
28		60307	SEAL, EXHAUST PLATE	1	
29		60306	STRIP, RETAINING - EXHAUST	1	
30	10	62568	SCREW, RETAINING STRIP TO	4	
31		63007	MOUNT, RUBBER - EXHAUST PL	1	
32		49651A 1	GROUND STRAP ASSY, EXHAU	1	
33	12	20346	WASHER, RUBBER MOUNT ATT.	2	
34	11	20261	NUT, RUBBER MOUNT TO EXHA	2	