



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1554	4813A 2	DRIVE SHAFT HOUSING ASSEM	1		
1	1564	4812A 2	DRIVE SHAFT HOUSING ASSEM	1		
2	19	64649	PLUG, PLASTIC-TRIM TAB SCR	1		
3	16	57932	STUD, DRIVE SHAFT HOUSING	1		
4	16	57935	STUD, DRIVE SHAFT HOUSING	1		
5	12	65791	WASHER, GEAR HOUSING TO D	2		
6	11	34933	NUT, GEAR HOUSING TO DRIVE	2		
7		47835	ROD, PUSH-REVERSE LOCK (SH	1		
7		47836	ROD, PUSH-REVERSE LOCK (LOI	1		
8	11	28770	NUT, JAM-PUSH ROD	1		
9		47837	ROD END, PUSH ROD	1		
10	17	39023	PIN, PUSH ROD TO REVERSE LC	1		
11	18	25191	COTTER PIN, PUSH ROD PIN	1		
12		75105	GUIDE, PUSH ROD	1		
13		35474	COVER, LOWER MOUNT CLAMP	2		
14	10	29722	SCREW, COVER TO LOWER MOU	2		
15	11	35521	NUT, LOWER MOUNT CLAMP CC	2		
16		69592	CLAMP, LOWER MOUNT TO DRIP	2		
17	10	29256	SCREW, LOWER MOUNT CLAMP	4		
18	24	35522	SPRING, TENSION-LOWER MOU	4		
19		37395	MOUNT, RUBBER-LOWER	2		
20	10	49318	SCREW, LOWER MOUNT (5 1/2"	2		
21	12	28051	WASHER, MOUNT SCREW	2		
22	12	28053	WASHER, RUBBER-LOWER MOL	2		
23	12	61709	WASHER, LOWER MOUNT SCRE	2		
24	11	25096	NUT, LOWER MOUNT SCREW	2		
25		66883	MOUNT, RUBBER-UPPER	2		
25A	25	65936	"O"RING, UPPER MOUNT	2		4
26		24929	PACKING, "U" CUP-UPPER MOUT	2		
27		24935	COVER, UPPER MOUNT-OUTSID	2		
28		31120	COVER, UPPER MOUNT-INSIDE	2		
29	10	71959	SCREW, UPPER MOUNT COVER	4		
30	10	71958	SCREW, UPPER MOUNT COVER	4		
30A	12	29245	WASHER, UPPER MOUNT COVE	8		
31	11	36069	NUT, UPPER MOUNT COVER SC	8		
32	12	27727	WASHER, UPPER MOUNT BOLT	2		
33	12	66966	WASHER, RUBBER-UPPER MOL	2		
34	12	30514	WASHER, UPPER MOUNT BOLT	2		
33	12	66966	WASHER, RUBBER-UPPER MOU	2		
34	12	30514	WASHER, UPPER MOUNT BOLT	2		
35	11	24922	NUT, UPPER MOUNT BOLT	2		