



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
1		65913	HOUSING, NYLON-THROTTLE ACTUATOR	1			
2		73334	CAM, NYLON-THROTTLE ACTUATOR	1			
3	10	37571	SCREW, HOUSING TO CRANKCASE	1			
4	13	26996	LOCKWASHER, HOUSING TO CRANKCASE	1			
5		60570	PLATE, RETAINER-ACTUATOR HOUSING	1			
6	23	74213	BARREL, NYLON-THROTTLE LINK ROD	1			
7		74164	ROD, LINK-THROTTLE	1			
8		73783	SWIVEL, LINK ROD TO THROTTLE CONTROL	1			
9	23	26856	BUSHING, LINK ROD SWIVEL	2			
10	12	33786	WASHER, LINK ROD SWIVEL	2			
11	11	45774	NUT, LINK ROD SWIVEL	2			
12		74304	LEVER, THROTTLE CONTROL	1			
13	10	73655	SCREW, ADJUSTING-THROTTLE CONTROL	2			
14	11	29598	NUT, JAM-ADJUSTING SCREW	2			
15		52023	CAP, ADJUSTING SCREW	2			
16	10	55337	SCREW, THROTTLE CONTROL LEVER	1			
17	23	55164	BUSHING, THROTTLE CONTROL LEVER	1			
18	23	55171	BUSHING, THROTTLE CONTROL LEVER	1			
19	24	55162	SPRING, RETURN-SPARK ADVANCE	1			
20		74402	LEVER, SPARK ADVANCE	1			
21	12	28008	WASHER, THROTTLE CONTROL LEVER	1			
22	10	73656	SCREW, SPARK ADVANCE ADJUSTING	1			
23	11	20645	NUT, SPARK ADVANCE ADJUSTING	1			
24		48039	CAP, SPARK ADVANCE ADJUSTING	1			
25	10	73655	SCREW, ADJUSTING-SPARK ADVANCE	1			
26	11	29598	NUT, JAM-ADJUSTING SCREW	1			
27		52023	CAP, ADJUSTING SCREW	1			
28		39483	LATCH, THROTTLE CONTROL LEVER	1			
29	10	22486	SCREW, LATCH TO THROTTLE CONTROL LEVER	1			
30	24	20099	SPRING, COMPRESSION-LATCH	1			
31	11	20586	NUT, LATCH ATTACHING SCREW	1			
32		74897	BARREL, LINK ROD TO STATOR	1			
33		74212	ROD, LINK-SPARK ADVANCE	1			
34		73783	SWIVEL, LINK ROD TO SPARK ADVANCE	1			