



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	450	4393A	2 CRANKSHAFT ASSEMBLY	1		
2	30	64424	BEARING, BALL - LOWER AND	2		
3	15	22369A	1 SHIM, LOWER BEARING TO CRA	AR		
4		60834A	3 CARRIER ASSEMBLY, "O" RING	1		
5		64254	"O" RING, CARRIER	1		2,3,4
6	542	4846A	7 MAIN BEARING ASSEMBLY (VAL)	2		
7	17	20032	DOWEL PIN, MAIN BEARING	4		
8	17	60282	DOWEL PIN (STEPPED)	2		
9	17	65855	DOWEL PIN, REED STOP	16		
10	34	66051A	1 REED SET, MATCHED - MAIN B	2		
11	34	65946	REED STOP	8		
12	10	53481	SCREW, REED STOP MOUNTIN	8		
13	11	20110	NUT, REED STOP MOUNTING	8		
14	10	45775	SCREW, MAIN BEARING CLAM	4		
15	11	45774	NUT, MAIN BEARING SCREW	4		
16		26113	RACE, OUTER (PAIR)	2		
17	53	26933	RING, SNAP - OUTER RACE	2		
18	29	52168	BEARING, NEEDLE	112		
19	745	5218A	3 PISTON AND PISTON PIN ASSE	3		
20	40	52035	LOCK RING, PISTON PIN	6		
21	39	45155A	12 RING, PISTON	1		
22	622	4850A	3 CONNECTING ROD AND CAP AS	3		
23	10	54803	SCREW, CAP TO CONNECTING	6		
24	11	49091	NUT, CONNECTING ROD SCRE	6		
25	31	62596A	1 BEARING ASSEMBLY, CRANKP	3		
26	29	47270	87 BARING, NEEDLE - PISTON PIN			
27	12	47247	6 WASHER, NEEDLE LOCATING			
--	745	5303A	2 PISTON AND PISTON PIN ASSE	3	OVERSIZE PISTON AND RING	
--	39	45204A	12 RING, PISTON (.015)	1	OVERSIZE PISTON AND RING	