



| Parts List | | | | | | |
|------------|-------|--------|-------------------------------|-------|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 33155 | WIRING HARNESS, INTERNAL | 1,1 | | |
| 2 | | 30050 | TERMINAL, HARNESS AND SW | AR,AR | | |
| 3 | | 26079 | PLATE, WIRING HARNESS TO B | 1,1 | | |
| 4 | 10 | 26128 | SCREW, WIRING HARNESS AND | 4,4 | | |
| 5 | 24 | 28975 | SPRING, GARTER - INTERNAL W | 1,1 | | |
| 6 | 54 | 22783 | "S" CLIP, RECTIFIER HARNESS L | 2,2 | | |
| 7 | | 30212 | BLOCK, TERMINAL - EXHAUST C | 1,1 | | |
| 8 | 10 | 33152 | SCREW, HARNESS LEADS TO T | 2,2 | | |
| 9 | 10 | 30663 | SCREW, TERMINAL BLOCK TO E | 2,2 | | |
| 10 | 50 | 31976 | STARTER MOTOR ASSEMBLY (D | 1,1 | | |
| 11 | 10 | 22698 | SCREW, STARTER MOTOR TO C | 2,2 | | |
| 12 | 13 | 26993 | LOCKWASHER, STARTER MOTO | 2,2 | | |
| 13 | 10 | 29197 | SCREW, WIRING HARNESS GRC | 1,1 | | |
| 14 | | 31057 | PLATE, SPACER - STARTER MO | 1,1 | | |
| 15 | | 29930 | BRACKET, SUPPORT - STARTER | 1,1 | | |
| 16 | 13 | 24669 | LOCKWASHER, THRU BOLT - BR | 2,2 | | |
| 17 | 11 | 20890 | NUT, THRU BOLT - BRACKET TO | 2,2 | | |
| 18 | 54 | 22740 | CLIP, HARNESS LEAD WIRES TC | 1,1 | | |
| 19 | | 22789 | "D" WASHER, CLIP FASTENING | 1,1 | | |
| 20 | 10 | 30009 | SCREW, LEAD WIRE CLIP FASTE | 1,1 | | |
| 21 | 54 | 23567 | CLIP, HARNESS LEAD WIRE TO | 1,1 | | |
| 22 | | 22789 | "D" WASHER, CLIP FASTENING | 1,1 | | |
| 23 | 10 | 30009 | SCREW, LEAD WIRE CLIP FASTE | 1,1 | | |
| 24 | | 32445 | SOLENOID, STARTER | 1,1 | | |
| 25 | 10 | 31208 | SCREW, SOLENOID TO STARTE | 2,2 | | |
| 26 | 13 | 26996 | LOCKWASHER, SOLENOID TERN | 2,2 | | |
| 27 | 11 | 20645 | NUT, SOLENOID TERMINAL (#10 | 2,2 | | |
| 28 | | 28016A | GROUND STRAP ASSEMBLY, SO | 1,1 | | |
| 29 | | 25596 | CABLE, WIRE - SOLENOID TO ST | 1,1 | | |
| 30 | 13 | 26993 | LOCKWASHER, SOLENOID TERN | 2,2 | | |
| 31 | 11 | 20083 | NUT, SOLENOID TERMINAL (5/1 | 2,2 | | |
| 32 | | 32970 | RECTIFIER ASSEMBLY | 1,1 | | |
| 33 | 13 | 26993 | LOCKWASHER, RECTIFIER MO | 1,1 | | |
| 34 | 11 | 21929 | NUT, RECTIFIER MOUNTING S | 1,1 | | |
| 35 | 32 | 28373 | SLEEVE, RUBBER - RECTIFIER H | 3,3 | | |
| 36 | 10 | 29852 | SCREW, HARNESS AND STATOF | 3,3 | | |
| 37 | 11 | 29488 | NUT, HARNESS AND STATOR LE | 3,3 | | |