



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	45	33007	SHAFT, DRIVE - MAGNETO	1,1		
2		30434A 1	MAGNETO PILOT ASSEMBLY	1,1		
3	24	27944	SPRING, HORSESHOE - MAGNETO	1,1		
4	17	27962	PIN, ANCHOR - HORSESHOE SPR	1,1		
5		33020	STOP, SPARK ADVANCE - MAGN	1,1		
6	30	20066	BEARING, BALL - MAGNETO PILC	1,1		
7	10	30110	SCREW, PILOT ASSEMBLY TO M	4,4		
8		33870A 1	ECONOMISER COLLAR AND PIN	1,		
8		35610A 1	ECONOMISER COLLAR AND PIN	,1		
9	17	27961	PIN, ECONOMISER COLLAR - S	1,1		
10	22	25094	FITTING, GREASE - ECONOMISEI	1,1		
11		33147A 1	THROTTLE ACTUATOR ASSEMB	1,1		
12	23	26602	BUSHING, NYLON - THROTTLE	1,1		
13	10	32078	SCREW, THROTTLE ACTUATOR	2,2		
14		30408	ADAPTOR, MAGNETO	1,1		
15	22	25094	FITTING, GREASE - MAGNETO AD	1,1		
16	10	22040	SCREW, MAGNETO ADAPTOR AD	3,3		
17	12	20084	WASHER, MAGNETO ADAPTOR,	3,3		
18	11	20083	NUT, MAGNETO ADAPTOR AND	3,3		
19	12	27939	WASHER, MAGNETO PILOT	1,1		
20	14	27960	TAB WASHER, ADAPTOR CAP F	1,1		
21	13	27959	WASHER, WAVE - MAGNETO BA	1,1		
22		27955	CAP, MAGNETO ADAPTOR AND I	1,1		
23	23	29909	SPACER, DRIVEN PULLEY	1,1		
24		29906A 1	DRIVEN PULLEY ASSEMBLY	1,1		
25	17	29908	PIN, ROLL - FLANGE LOCATING	1,1		
26		29907	FLANGE, DRIVEN PULLEY	1,1		
27	28	29910	KEY, MAGNETO DRIVING	1,1		
28	13	26996	LOCKWASHER, PULLEY CLAMP	1,1		
29	10	29911	SCREW, PULLEY CLAMPING	1,1		
30		20140	BELT, TIMING	1,1		