



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	182	1895A 2	TOP COWL ASSEMBLY	1,1		
2	16	33071	STUD, FRONT-TOP COWL TO C	2,2		
3	25	20116	GROMMET, CHOKE KNOB	1,1		
4	23	33070	SPACER, TOP COWL FRONT STL	2,2		
5		31476	REVEAL, AIR INTAKE	1,1		
6	10	30841	SCREW, REVEAL TO TOP COWL	2,2		
7	13	26996	LOCKWASHER, REVEAL TO TOP	2,2		
8		29947	SCREEN, VENT-TOP COWL	1,1		
9	10	29221	SCREW, VENT SCREEN TO TOP	2,2		
10		31298A 1	PLATE ASSEMBLY, COWL MOUN	1,1		
11	16	20353	STUD, REAR-TOP COWL TO CC	2,2		
12	10	31299	SCREW, PLATE ASSEMBLY TO T	3,3		
13	12	20028	WASHER, TOP COWL STUD (1/1	4,4		
14	12	20346	WASHER, TOP COWL STUD (3/4	4,4		
15	12	20583	WASHER, TOP COWL STUD (1/3	AR,AR		
16	11	20361	NUT, TOP COWL FASTENING	4,4		
17		20155	RETAINER, STARTER SPRING	1,1		
18	24	29340A 1	SPRING, STARTER REWIND	1,1		
19	23	28912	BUSHING, SPRING GUIDE	1,1		
20	50	30994	SHEAVE ASSEMBLY	1,1		
21		30596	PAWL, STARTER	3,3		
22	13	30597	WASHER, WAVE-STARTER PAW	3,3		
23	23	28919	BUSHING, NYLON-SHEAVE SHAF	1,1		
24	23	28911	SPACER, SHEAVE SHAFT	1,1		
25		26179	RETAINER, WAVE WASHER	1,1		
26	12	26180	WASHER, SHEAVE SHAFT TO S1	1,1		
27	13	20160	WASHER, WAVE-WASHER TENE	1,1		
28		30595	PLATE, RETAINER-STARTER PA	1,1		
29		28913	SHAFT, SHEAVE	1,1		
30	14	20165	TAB WASHER, SHEAVE SHAFT	1,1		
31	11	20166	NUT, SHEAVE SHAFT (LEFT HAN	1,1		
32	50	28985A 1	STARTER CABLE ASSEMBLY	1,1		
33		28747	HANDLE, STARTER CABLE	1,1		
34		28748	RETAINER, STARTER CABLE AN	1,1		
35		30045	PLATE, ROPE GUIDE SEE NOTE	1,1	REFERENCE NUMBERS 35 AND	
36	10	28642	SCREW, DRIVE-ROPE GUIDE PL	3,3	REFERENCE NUMBERS 35 AND	
35		35800	PLATE, ROPE GUIDE	,1	REFERENCE NUMBERS 35 AND	
36	10	35881	SCREW, DRIVE-ROPE GUIDE PL	,3	REFERENCE NUMBERS 35 AND	
37		31463	HANDLE, CHROME-TOP COWL	1,1		
38		31487	HANDLE ASSEMBLY, INSIDE-TOP	1,1		
39		20295	PAD, RUBBER TOP COWL HAN	1,1		