



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	45	33007	SHAFT, DRIVE - MAGNETO	1,1		
2		30434A 1	MAGNETO PILOT ASSEMBLY	1,1		
2		39561A 1	MAGNETO PILOT ASSEMBLY	,1		
3	24	27944	SPRING, HORSESHOE - MAGNETO	1,1		
4	17	27962	PIN, ANCHOR - HORSESHOE SP	1,1		
5		33020	STOP, SPARK ADVANCE - MAGN	1,1		
6	30	20066	BEARING, BALL - MAGNETO TO M	1,1		
7	10	30110	SCREW, PILOT ASSEMBLY TO P	4,4		
8		35610A 1	ECONOMIZER COLLAR AND PIN	1,1		
9	17	27961	PIN, ECONOMIZER COLLAR - S	1,1		
11		33147A 1	THROTTLE ACTUATOR ASSEMB	1,1		
10	22	25094	FITTING, GREASE - ECONOMIZE	1,1		
12	23	26602	BUSHING, NYLON - THROTTLE	1,1		
14		30408	ADAPTOR, MAGNETO	1,1		
15	22	25094	FITTING, GREASE - MAGNETO A	1,1		
16	10	22040	SCREW, MAGNETO ADAPTOR A	3,3		
17	12	20084	WASHER, MAGNETO ADAPTOR	3,3		
18	11	20083	NUT, MAGNETO ADAPTOR AND	3,3		
19	12	27939	WASHER, MAGNETO PILOT	1,1		
20	14	27960	TAB WASHER, ADAPTOR CAP F	1,1		
21	13	27959	WASHER, WAVE - MAGNETO BA	1,1		
22		27955	CAP, MAGNETO ADAPTOR AND	1,1		
23	23	29909	SPACER, DRIVEN PULLEY	1,1		
24		29906A 1	DRIVEN PULLEY ASSEMBLY	1,1		
25	17	29908	PIN, ROLL - FLANGE LOCATING	1,1		
26		29907	FLANGE, DRIVEN PULLEY	1,1		
27	28	29910	KEY, MAGNETO DRIVING	1,1		
28	13	26996	LOCKWASHER, PULLEY CLAMP	1,1		
29	10	29911	SCREW, PULLEY CLAMPING	1,1		
30		20140	BELT, TIMING	1,1		