



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1440	1796A 1	CLAMP BRACKET ASSEMBLY	2,2		
2		28403A 3	THUMB SCREW ASSEMBLY	2,2		
3		28404	WASHER, THUMB SCREW	2,2		
4	...C	30664	TUBE, TILT - CLAMP BRACKET T	1,1		
5	15	30497A 1	SHIM, CLAMP BRACKET TILT TU	2,2		
6	11	30499	NUT, TILT TUBE FASTENING	2,2		
7		30498	CAP, PLASTIC - TILT TUBE	2,2		
8	23	20222	SPACER, CLAMP BRACKET STUC	1,1		
9	16	20221	STUD, CLAMP BRACKET	2,2		
10	13	26993	LOCKWASHER, CLAMP BRACKET	2,2		
11	11	20083	NUT, CLAMP BRACKET STUD	2,2		
12	17	30687A 1	TILT LOCK PIN ASSEMBLY	1,1		
13	32	28052	SLEEVE, RUBBER - TILT LOCK PI	1,1		
14	10	28009	BOLT, CLAMP BRACKET TO BOA	2,2		
15	12	28008	WASHER, CLAMP BRACKET BOL	2,2		
16	11	28010	NUT, CLAMP BRACKET BOLT	2,2		
17	55	28416	PIN, UPPER SHOCK MOUNTING	1,1		
18		30126A 1	TILT STOP LEVER ASSEMBLY	1,1		
19	10	30128	SCREW, TILT STOP LEVER ANCH	2,2		
20	13	31030	WASHER, WAVE - LEVER ANCH	2,2		
21	11	29250	NUT, LEVER ANCHOR SCREW	2,2		
22	1447	1945A 3	SWIVEL BRACKET ASSEMBLY (L	1,	LONG SHAFT	
23	26	31783	OIL SEAL, SWIVEL BRACKET	2,	LONG SHAFT	
22	1453	2461A 1	SWIVEL BRACKET ASSEMBLY(U:	1,	SHORT SHAFT	
22	1453	2690A 1	SWIVEL BRACKET ASSEMBLY(U:	1,	SHORT SHAFT	
22	1447	2462A 3	SWIVEL BRACKET ASEMBLY(US	1,	LONG SHAFT	
22	1447	2689A 1	SWIVEL BRACKET ASSEMBLY(U:	2,	LONG SHAFT	
23	26	37448	OIL SEAL, SWIVEL BRACKET	2,2		
24	22	23612	FITTING, GREASE	1,1		
25		29359	LUBRICAP, SWIVEL BRACKET Gf	1,1		
26	17	37462A 1	SWIVEL PIN AND STEERING ARM	1,		
26	17	31773A 2	SWIVEL PIN AND STEERING ARM	1,1		
26	17	37423A 1	SWIVEL PIN AND STEERING ARM	1,1		
27		28203	BUMPER, STEERING ARM	1,1		
28	10	30453	BOLT, STEERING ARM TO UPPE	2,2		
29	11	22178	NUT, STEERING ARM BOLT FAS	2,2		
30	12	37429	WASHER, SWIVEL PIN - LOWER	1,		
30	12	31815	WASHER, SWIVEL PIN - LOWER	1,1		
31	10	31830	SCREW, RIDE-GUIDE ATTACHIN	1,1		
32	11	20509	NUT, RIDE-GUIDE ATTACHING S	1,1		
32	28	28784	SERIAL PLATE	1,1		