



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	393	2799A 7	DISTRIBUTOR ASSEMBLY, COM	1	SERIAL 00000000-32215200	
-	393	2799A20	DISTRIBUTOR ASSEMBLY, COM	1	SERIAL 02215201-09999999	
1	393	2799	HOUSING, PRIMARY	1		
2	13	26317	WASHER, WAVE - PRIMARY HO	2		
3	393	2795	SHIM, TRIGGER HOUSING TO I	AR		
4	393	2918A 3	TRIGGER HOUSING ASSEMBL	1		
5	53	45906	RING, RETAINER - ROTOR SHA	2		
6	30	26379	BEARING, BALL - ROTO SHAFT	2		
7	393	2921A 3	ROTOR SHAFT ASSEMBLY	1	SERIAL 00000000-02215200	
7	393	2921A 5	ROTOR SHAFT ASSEMBLY	1	SERIAL 02215201-09999999	
9	393	3014A 2	ADAPTOR ASSEMBLY, HOUSIN	1		
8	17	20032	DOWEL PIN, ADAPTOR TO PI	2		
10	27	46351	GASKET, ADAPTOR TO PRIM	1		4
10	27	45910	GASKET, ADAPTOR TO PRIMAI	1		4
11	10	32627	SCREW, ADAPTOR TO HOUSIN	2		
12	11	46438	NUT, ADAPTOR TO HOUSIN	2		
13	10	20646	SCREW, SHIM AND TRIGGER	2		
14	23	32914	SLEEVE, TRIGGER HOUSING C	1		
15	22	31521A 1	ELBOW ASSEMBLY, VENT HOSE	1		
16	27	36268	GASKET, DISTRIBUTOR CAP T	1		4
17	393	2955A 2	DISTRIBUTOR CAP ASSEMBLY	1		
18	22	31521	ELBOW, VENT HOSE - DISTR	1		
19	393	1293A 1	BRUSH AND SPRING ASSEM	1		
20	10	45914	SCREW, DISTRIBUTOR CAP TC	4		
21	12	26436	WASHER, DISTRIBUTOR CAP F	4		
22	11	46438	NUT, DISTRIBUTOR CAP FAST	4		
23	393	3018A 1	HIGH TENSION CABLE ASSEM	1		
--		20121	CONNECTOR, HIGH TENSION	1		
24	332	2854	BOOT, HIGH TENSION CABLE	1		
25	393	1275	SLEEVE, HIGH TENSION CAB	1		
27	32	46398	SLEEVE, HIGH TENSION CAB	1		
28		23564A 8	SPARK PLUG LEAD ASSEMBLY	1	ORDER A-36549A1 KIT FOR REF	
28		23564A 9	SPARK PLUG LEAD ASSEMBLY	3	ORDER A-36549A1 KIT FOR REF	
--		20121	CONNECTOR, SPARK PLUG L	4		
25	393	1275	SLEEVE, SPARK PLUG LEAD TI	4		
29		20119A 1	PROTECTOR, SPARK PLUG LE	4		
30	32	46768	SLEEVE (LEADS 1, 2, 3, 4) - 6"	2		
31	32	26527	SLEEVE, HIGH TENSION LEAD	2		