



| Parts List | | | | | | |
|------------|-------|----------|------------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 45 | 46247 | SHAFT, DRIVE - DISTRIBUTOR | 1 | | |
| 2 | | 46242A 1 | DISTRIBUTOR PILOT ASSEMBLY | 1 | | |
| 3 | 24 | 27944 | SPRING, HORSESHOE - DISTRIB | 1 | | |
| 4 | 17 | 27962 | PIN, ANCHOR - HORSESHOE SPF | 1 | | |
| 6 | 53 | 46250 | RING, SNAP - BALL BEARING RE | 1 | | |
| 7 | 30 | 20066 | BEARING, BALL - DISTRIBUTOR | 1 | | |
| 8 | 10 | 29281 | SCREW, PILOT ASSEMBLY TO D | 4 | | |
| 9 | | 35610A 1 | ECONOMIZER COLLAR AND PIN | 1 | | |
| 10 | 17 | 27961 | PIN, ECONOMIZER COLLAR - S | 1 | | |
| 11 | 22 | 25094 | FITTING, GREASE - ECONOMIZEI | 1 | | |
| 12 | | 33147A 1 | THROTTLE ACTUATOR ASSEMB | 1 | | |
| 13 | 23 | 26602 | BUSHING, NYLON - THROTTLE | 1 | | |
| 14 | 10 | 46420 | SCREW, THROTTLE ACTUATOR | 2 | | |
| 15 | 12 | 46246 | WASHER, PILOT TO DISTRIBUTO | 1 | | |
| 16 | | 30043 | ADAPTOR, DISTRIBUTOR | 1 | | |
| 17 | 22 | 25094 | FITTING, GREASE - DISTRIBUTO | 1 | | |
| 18 | 10 | 22040 | SCREW, DISTRIBUTOR ADAPTO | 3 | | |
| 19 | 12 | 20084 | WASHER, DISTRIBUTOR ADAPT | 3 | | |
| 20 | 11 | 20083 | NUT, DISTRIBUTOR ADAPTOR A | 3 | | |
| 21 | 12 | 27939 | WASHER, DISTRIBUTOR PILOT | 1 | | |
| 22 | 53 | 20067 | RING, SNAP - BALL BEARING RE | 1 | | |
| 23 | 30 | 20066 | BEARING, BALL - DISTRIBUTOR | 1 | | |
| 24 | 14 | 27960 | TAB WASHER, ADAPTOR CAP F/ | 1 | | |
| 25 | 13 | 27959 | WASHER, WAVE - DISTRIBUTOF | 1 | | |
| 26 | | 27955 | CAP, DISTRIBUTOR ADAPTOR A | 1 | | |
| 27 | 23 | 29909 | SPACER, DRIVE PULLEY | 1 | | |
| 28 | | 29906A 1 | DRIVEN PULLEY ASSEMBLY | 1 | | |
| 29 | 17 | 29908 | PIN, ROLL - FLANGE LOCATING | 1 | | |
| 30 | | 29907 | FLANGE, DRIVEN PULLEY | 1 | | |
| 31 | 28 | 29910 | KEY, DISTRIBUTOR DRIVING | 1 | | |
| 32 | 13 | 26396 | LOCKWASHER, PULLEY CLAMPPI | 1 | | |
| 33 | 10 | 29911 | SCREW, PULLEY CLAMPING | 1 | | |
| 34 | | 20140 | BELT, TIMING | 1 | | |