



| Parts List |       |          |                             |     |         |          |
|------------|-------|----------|-----------------------------|-----|---------|----------|
| Ref        | Class | Part     | Description                 | Qty | Comment | Footnote |
| 1          | 2104  | 2654A 7  | COWL FRONT COVER ASSEMBLY   | 1,1 |         |          |
| 2          |       | 32362    | KNOB, COWL FRONT COVER F.   | 1,1 |         |          |
| 3          | 12    | 30771    | WASHER, COVER FASTENING     | 2,2 |         |          |
| 4          | 12    | 27129    | WASHER, COVER FASTENING     | 2,2 |         |          |
| 5          | 24    | 32271    | SPRING, TENSION - COVER FA  | 1,1 |         |          |
| 6          | 17    | 29077    | ROLL PIN, TENSION SPRING T  | 1,1 |         |          |
| 7          |       | 38674    | BLANKET, SOUND ABSORBING    | 1,1 |         |          |
| 8          |       | 31095    | STRIP, SOUND - LOWER SECT   | 2,2 |         |          |
| 9          |       | 35552    | SEAL, SOUND - UPPER SECTIC  | 1,1 |         |          |
| 10         | 2119  | 2657A 3  | WRAP AROUND COWL ASSEMBLY   | 1,1 |         |          |
| 11         |       | 38961    | HANDLE, COWL LATCH -EARLY   | 2,2 |         |          |
| 12         | 17    | 21057    | PIN, HINGE - HANDLE TO COWL | 4,4 |         |          |
| 13         | 53    | 21058    | "E" RING, HANDLE TO COWL L  | 4,4 |         |          |
| 14         |       | 38964    | SWIVEL, COWL LATCH -EARLY   | 2,2 |         |          |
| 15         |       | 46785A 1 | COWL LATCH ASSEMBLY (LATE)  | 2,2 |         |          |
| 16         |       | 30413    | HOOK, COWL LATCH FASTENING  | 2,2 |         |          |
| 17         |       | 31935    | BLANKET, SOUND ABSORBING    | 1,1 |         |          |
| --         | 92    | 25234 1  | GLUE, ADHESIVE - SOUND BLAN | 1,1 |         |          |