



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	45	33007	SHAFT, DRIVE - MAGNETO	1		
2		39561A 1	MAGNETO PILOT ASSEMBLY	1		
3	24	27944	SPRING, HORSESHOE - MAGNETO	1		
4	17	27962	PIN, ANCHOR - HORSESHOE SP	1		
5		33020	STOP, SPARK ADVANCE - MAGN	1		
7	30	20066	BEARING, BALL - MAGNETO PILC	1		
8	10	30110	SCREW, PILOT ASSEMBLY TO M	4		
9		35610A 1	ECONOMIZER COLLAR AND PIN	1		
10	17	27961	PIN, ECONOMZIER COLLAR - S	1		
11	22	25094	FITTING, GREASE - ECONOMIZEI	1		
12		33147A 1	THROTTLE ACTUATOR ASSEMB	1		
13	23	26602	BUSHING, NYLON - THROTTLE	1		
14	10	46420	SCREW, THROTTLE ACTUATOR	2		
16		30408	ADAPTOR, MAGNETO	1		
17	22	25094	FITTING, GREASE - MAGNETO AI	1		
18	10	22040	SCREW, MAGNETO ADAPTOR AI	3		
19	12	20084	WASHER, MAGNETO ADAPTOR	3		
20	11	20083	NUT, MAGNETO ADAPTOR AND	3		
21	12	27939	WASHER, MAGNETO PILOT	1		
24	14	27960	TAB WASHER, ADAPTOR CAP FZ	1		
25	13	27959	WASHER, WAVE - MAGNETO BA	1		
26		27955	CAP, MAGNETO ADAPTOR AND I	1		
27	23	29909	SPACER, DRIVE PULLEY	1		
28		29906A 1	DRIVEN PULLEY ASSEMBLY	1		
29	17	29908	PIN, ROLL - FLANGE LOCATING	1		
30		29907	FLANGE, DRIVEN PULLEY	1		
31	28	29910	KEY, MAGNETO DRIVING	1		
32	13	26996	LOCKWASHER, PULLEY CLAMP	1		
33	10	29911	SCREW, PULLEY CLAMPING	1		
34		20140	BELT, TIMING	1		