



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		37408	HANDLE, CHROME - TOP COWL	1,1		
2	12	20533	WASHER, CHROME HANDLE TO	6,6		
3	12	21631	WASHER, CHROME HANDLE TO	AR,AR		
4	11	20361	NUT, CHROME HANDLE TO INSID	4,4		
5		35496	PAD, BUMPER - TOP COWL HAN	1,1		
6		37434	HANDLE, INSIDE - TOP COWL	1,1		
7	10	24234	SCREW, HANDLE TO TOP COWL	2,2		
8	13	26993	LOCKWASHER, HANDLE TO TOP	2,2		
9	2114	2455	COWL, TOP	1,1		
10		37410A 1	TRIM MOULDING ASSEMBLY, TC	1,1		
11	10	29227	SCREW, BRASS - MOULDING T	2,2		
12	10	29226	SCREW, DECORATIVE - MOULI	2,2		
13	13	26995	LOCKWASHER, MOULDING FA	4,4		
14	11	26419	NUT, MOULDING FASTENING	4,4		
15		37569	SHIELD, TOP COWL - REAR	1,1		
16	10	37370	SCREW, SHIELD TO TOP COWL	3,3		
17	13	37371	LOCKWASHER, SHIELD SCREW	3,3		
18	50	37901	ROPE, STARTER (FOR MANUAL	1,1		
19		37411	BRACKET, COWL LATCH - TOP C	2,2		
20	10	3756	SCREW, COWL LATCH BRACKET	4,4		
21	11	37556	NUT, COWL LATCH BRACKET SC	4,4		
22		37409	FRAME, TOP COWL SUPPORT	1,1		
23	37	45201	DECAL, TIMING - TOP COWL FRA	1,1		
24		37639	MOUNT, RUBBER - TOP COWL F	3,3		
25	11	20361	NUT, RUBBER MOUNT TO TOP C	6,6		
26		46170	BRACKET, TOP COWL SUPPORT	1,1		
27		31014	MOUNT, RUBBER - REAR SUPPC	2,2		
--	12	20346	WASHER, RUBBER MOUNT STU	2,2		
28	13	26992	LOCKWASHER, RUBBER MOUNT	2,2		
29	11	20088	NUT, RUBBER MOUNT TO REAR	2,2		
30	10	26065	SCREW, REAR SUPPORT BRACK	4,4		
31	11	46793	NUT, REAR SUPPORT BRACKET	4,4		
32	10	37558	SCREW, REAR SUPPORT BRACK	2,2		
33	13	26993	LOCKWASHER, REAR SUPPORT	2,2		
34		37412	LEVER, CLAMPING - TOP COWL	2,2		
35	23	26819	BUSHING, NYLON - CLAMPING LI	2,2		
36	12	38006	WASHER, CLAMPING LEVER	2,2		
37	23	31293	BUSHING, RUBBER - CLAMPING	2,2		
38	53	30428	FASTENER, CLAMPING LEVER	2,2		
39	17	29077	PIN, ROLL - CLAMPING LEVER	2,2		
40		46200A 2	BRACKET ASSEMBLY, TOP COWL	1,1		