



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	19	45307	PLUG, FLYWHEEL PULLER THRE	1,1,1		
2	11	22339	NUT, FLYWHEEL	1,1,1		
3	12	33001	WASHER, FLYWHEEL NUT	1,1,1		
4	28	45554	KEY, FLYWHEEL DRIVE	1,1,1		
5	225	2498A 6	FLYWHEEL ASSEMBLY, COMPLE	1,		
5	225	2498A 5	FLYWHEEL ASSEMBLY, COMPLE	,1,	SERIAL 00000000-02446774	
5	225	2498A 8	FLYWHEEL ASSEMBLY, COMPLE	,1,1	SERIAL 02446775-09999999	
6	10	32417	SCREW, FLEXIBLE PLATE TO F	1,1,1		
7	10	49006	SCREW, PLATE AND HUB TO F	8,8,8		
8	17	26618	PINE, DOWELL - PULLEY TO FL	1,1,1		
9		29788	FLANGE, FLYWHEEL PULLEY	1,1,1		
10		30306	PULLEY, FLYWHEEL	1,1,1		
11		29787	HUB, FLYWHEEL PULLEY	1,1,1		
12	398	2997	STATOR, ALTERNATOR	,1,		
12	398	3687	STATOR, ALTERNATOR	,,1		
13		30050	TERMINAL, STATOR LEAD WIF	,2,2		
14	10	52720	SCREW, STATOR TO UPPER EN	,4,4		
15	54	22740	CLIP, STATOR LEAD TO UPPER I	,1,1		
16	10	34222	SCREW, STATOR LEAD CLIP FAS	,1,1		
17		22789	"D" WASHER, CLIP FASTENING :	,1,1		
18	54	46409	CLIP, STATOR LEAD CLIP TO TO	,1,1		