



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	333	3213A 3	SWITCH BOX ASSEMBLY, COMPLE	(1),(1),(	SERIAL J2446775-09999999	
1A	332	2986A 3	SWITCH BOX ASSEMBLY, COMPI	.1,		
2	12	45075	WASHER, SWITCH BOX TERMIN	3,3,3	SERIAL J2446775-09999999	
2	12	45075	WASHER, SWITCH BOX TERMIN	.7,		
3	11	45076	NUT, SWITCH BOX TERMINAL	4,4,4	SERIAL J2446775-09999999	
3	11	45076	NUT, SWITCH BOX TERMINAL	.7,		
4	10	24866	SCREW, SWITCH BOX TO FRON	4,4,4	SERIAL J2446775-09999999	
4A	10	22485	SCREW, SWITCH BOX TO FRON	.4,		
5	11	46887	NUT, SWITCH BOX TO FRONT SI	.4,		
6	332	2910A 3	RECTIFIER ASSEMBLY, COMPLE	.4,	SERIAL 00000000-02446774	
7	12	45075	WASHER, RECTIFIER TERMINAL	.3,	SERIAL 00000000-02446774	
8	11	45076	NUT, RECTIFIER TERMINAL	.3,	SERIAL 00000000-02446774	
10	10	22485	NUT, RECTIFIER TO FRONT SUF	.2,	SERIAL 00000000-02446774	
11		49184	RECTIFIER	.1,1	SERIAL 02446775-09999999	
12	13	26393	LOCKWASHER, RECTIFIER TO	.1,1	SERIAL 02446775-09999999	
13	11	20922	NUT, RECTIFIER TO RECTIFIER	.1,1	SERIAL 02446775-09999999	
14	10	29852	SCREW, RECTIFIER TERMINALS	.1,1	SERIAL 02446775-09999999	
15	11	29488	NUT, RECTIFIER TERMINALS	.3,3	SERIAL 02446775-09999999	
16	32	28373	SLEEVE, RECTIFIER TERMINALS	.3,3	SERIAL 02446775-09999999	
17		49730	BRACKET, RECTIFIER MOUNTIN	.1,	SERIAL 02446775-09999999	
18	10	29072	SCREW, RECTIFIER MOUNTING	.1,	SERIAL 02446775-09999999	
19	11	24656	NUT, RECTIFIER MOUNTING BR	.1,	SERIAL 02446775-09999999	
20	10	20776	SCREW, RECTIFIER MOUNTING	.1,	SERIAL 02446775-09999999	
21	13	24669	LOCKWASHER, RECTIFIER MOU	.1,	SERIAL 02446775-09999999	
17		53145	BRACKET, RECTIFIER MOUNTIN	.1,		
18	10	28192	SCREW, RECTIFIER MOUNTING	.2,		
22		46280	BRACKET, RETAINER - HIGH TE	1,1,1		
23	10	21722	SCREW, RETAINER BRACKET TI	1,1,		
23	10	22956	SCREW, RETAINER BRACKET TI	.1,		
24	11	46887	NUT, RETAINER BRACKET SCRE	1,1,1		
25	50	45822A 1	STARTER MOTOR ASSEMBLY	1,1,1		
26	13	26392	LOCKWASHER, STARTER MOTO	1,1,1		
27	11	20890	NUT, STARTER MOTOR TERMIN	1,1,1		
28	10	22698	SCREW, STARTER MOTOR TO C	2,2,2		
29	13	26393	LOCKWASHER, STARTER MOTO	2,2,2		
30		37331	PLATE, SPACER - STARTER MOT	1,1,1		
31		38747	BRACKET, SUPPORT - STARTER	1,1,1		
32	13	24669	LOCKWASHER, THRU BOLT - BR	2,2,2		
33	11	20088	NUT, THRU BOLT - BRACKET TO	2,2,2		
34		25596	WIRE, STARTER MOTOR TO ST	1,	SERIAL 00000000-02446774	
34		25596	WIRE, STARTER MOTOR TO ST	2,	SERIAL 00000000-02446774	