



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1335	3358	CARBURETOR ASSEMBLY, COMI	2,2		
1	1335	3683	CARBURETOR ASSEMBLY, COMI	,,2		
2	1399	110A 1	FLOAT ASSEMBLY	2,2,2		
3			PIN, FLOAT LEVER PINION	4,4,4		3
4			LEVER, FLOAT (LOWER)	2,2,2		3
5			LEVER, FLOAT (UPPER)	2,2,2		3
6	1399	1473	INLET NEEDLE, SEAT AND GA	2,2,2		3
7			GASKET, INLET SEAT	2,2,2		3,0
8			GASKET, FLOAT BOWL COVER	2,2,2		3,0
9	1399	1133	COVER, FLOAT BOWL	2,2,2		
10	10	20854	SCREW, FLOAT BOWL COVER	2,2		
11	10	25850	SCREW, FLOAT BOWL COVER	2,2		
10	10	52195	SCREW, FLOAT BOWL COVER	,,2		
11	10	52196	SCREW, FLOAT BOWL COVER	,,2		
12	13	52197	LOCKWASHER, FLOAT BOWL C	,,4		
13			GASKET, STRAINER COVER (L	2,2,2		3,0
14	1399	1754	SCREEN, FILTER	2,2,2		3
15			GASKET, STRAINER COVER (S	2,2,2		3,0
16	1399	1930	COVER, STRAINER	2,2,2		
17			GASKET, STRAINER COVER SC	2,2,2		3,0
18	10	25822	SCREW, STRAINER COVER FA	2,2,2		3
19	10	20847	SCREW, THROTTLE STOP LEV	2,2,2		3
20	1399	97	LEVER, THROTTLE STOP (SEE	2,2,2		
21	1399	2012	SHAFT, THROTTLE	2,2,2		
22			TUBE, IDLE	2,2,2		3
23			GASKET, IDLE TUBE	2,2,2		3,0
24			SCREW AND LOCKWSHER, TH	4,4,4		3
25	1399	3401	SHUTTER, THROTTLE	2,2,2		
26			SPRING, IDLE ADJUSTMENT S	2,2,2		3
27	1399	1713	SCREW, IDLE ADJUSTMENT	2,2,2		3
28	10	28405	SCREW, PLUG - MAIN FUEL JE	2,2,2		
29			GASKET, JET CHANNEL PLUG	2,2,2		3,0
30	1399	1463	JET, MAIN FUEL (.063)	OPT,0I		
30	1399	1461	JET, MAIN FUEL (.061) - STAND	2,2,2		3
30	1399	1459	JET, MAIN FUEL (.059)	OPT,0I		
30	1399	1457	JET, MAIN FUEL (.057)	OPT,0I		
31			GASKET, MAIN FUEL JET	2,2,2		3,0
32			NOZZLE, MAIN	2,2,2		3
33	10	28846	SCREW, PLUG - MAIN NOZZLE	2,2,2		
34			SPRING, THROTTLE SHAFT RE	1,1,1		3
34			SPRING, THROTTLE SHAFT RE	1,1,1		2