



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	45	47953	SHAFT, DRIVE - DISTRIBUTOR	1		
2		46242A	DISTRIBUTOR PILOT ASSEMBLY	1		
3	24	27944	SPRING, HORSESHOE - DISTRIB	1		
4	17	27962	PIN, ANCHOR - HORSESHOE SPF	1		
6	30	20066	BEARING, BALL - DISTRIBUTOR	1		
7	10	48291	SCREW, PILOT ASSEMBLY TO D	4		
8		48103A	ECONOMIZER COLLAR AND PIN	1		
9	17	27961	PIN, ECONOMIZER COLLAR - S	1		
10	22	25094	FITTING, GREASE - ECONOMIZEI	1		
11		48306	PLATE, THROTTLE ACTUATOR	1		
12	10	46420	SCREW, THROTTLE ACTUATOR	2		
13	10	23702	SCREW, ADJUSTING O THROTTL	1		
14	11	20645	NUT, THROTTLE ACTUATOR AD	1		
15		48039	CAP, THROTTLE ACTUATOR AD.	1		
16	12	46246	WASHER, PILOT TO DISTRIBUTO	1		
17		30043	ADAPTOR, DISTRIBUTOR	1		
18	22	25094	FITING, GREASE - DISTRIBUTOR	1		
19	10	22040	SCREW, DISTRIBUTOR ADAPTO	3		
20	12	20084	WASHER, DISTRIBUTOR ADAPT	3		
21	11	20083	NUT, DISTRIBUTOR ADAPTOR A	3		
22	12	27939	WASHER, DISTRIBUTOR PILOT	1		
23	14	27960	TAB WASHER, ADAPTOR CAP FZ	1		
24	13	27959	WASHER, WAVE - DISTRIBUTOF	1		
25		27955	CAP, DISTRIBUTING ADAPTOR A	1		
26	23	29909	SPACER, DRIVE PULLEY	1		
27		29906A	DRIVEN PULLEY ASSEMBLY	1		
28	17	29908	PIN, ROLL - FLANGE LOCATING	1		
29		29907	FLANGE, DRIVEN PULLEY	1		
30	28	29910	KEY, DISTRIBUTOR DRIVER	1		
31	13	26996	LOCKWASHER, PULLEY CLAMPII	1		
32	10	29911	SCREW, PULLEY CLAMPING	1		
33		20140	BELT, TIMING	1		