



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		30263A	FUEL PUMP ASSEMBLY-UPPER	1,1		
1		53156A	FUEL PUMP ASSEMBLY-UPPER	1,1		
2	21	30430A	CHECK VALVE ASSEMBLY	1,1		
3		23014A	DIAPHRAGM KIT	1,1		4
4			GASKET, FUEL PUMP COVE	1,1		4
5			GASKET, FUEL PUMP	2,2		4
6			GASKET, CHECK VALVE TO	2,2		4
7		23004	RETAINER, CHECK VALVE	1,1		
8	10	20037	SCREW, RETAINER TO HOUSII	2,2		
9		30461A	FUEL PUMP ASSEMBLY-LOWER	1,1		
2	21	30430A	CHECK VALVE ASSEMBLY	1,1		
3		23014A	DIAPHRAGM KIT	1,1		4
4			GASKET, FUEL PUMP COVE	1,1		4
5			GASKET, FUEL PUMP	2,2		4
6			GASKET, CHECK VALVE TO	2,2		4
7		23004	RETAINER, CHECK VALVE	1,1		
8	10	20037	SCREW, RETAINER TO HOUSII	2,2		
10		30275	COVER, FUEL PUMP	2,2		
11	10	29878	SCREW, PUMP MOUNTING (1-1/	1,1		
12	10	30274	SCREW, PUMP MOUNTING (1-3/	2,2		
11	10	38036	SCREW, PUMP MOUNTING (1-1/	1,1		
12	10	30273	SCREW, PUMP MOUNTING (1-7/	2,2		
13	10	38036	SCREW, PUMP MOUNTING (1-1/	1,1		
14	10	30273	SCREW, PUMP MOUNTING (1-7/	2,2		
15	32	33154A	FUEL LINE ASSY, PUMP TO CAR	1,1		
16	22	29085	ELBOW (45), UPPER CARBURETI	1,1		
17	22	30174	ELBOW, UPPER FUEL PUMP OU	1,1		
18	22	30175	SLEEVE, FUEL PUMP OUTLET EI	1,1		
19	22	30177	NUT, FUEL PUMP OUTLET ELBO	1,1		
20	32	31552A	FUEL LINE ASSY, PUMP TO PUM	1,1		
21	32	31553A	FUEL LINE ASSY, PUMP TO CAR	1,1		
22	32	30176	FUEL LINE, ADAPTOR TO LOWEI	1,1		
23	22	30174	ELBOW, LOWER FUEL PUMP INL	1,1		
24	22	30175	SLEEVE, FUEL PUMP INLET ELBI	1,1		
25	22	30177	NUT, FUEL PUMP INLET ELBOW	1,1		
26	22	37682	ELBOW, FUEL LINE TO ADAPTOR	1,1		
27		30186	ADAPTOR, CHECK UNIT (FUEL LI	1,1		
28		30187	STEM, CHECK UNIT ADAPTOR	1,1		
29	25	20415	"O" RING, ADAPTOR STEM	1,1		4
30	24	30189	SPRING, ADAPTOR STEM	1,1		
31		20188	CURV/WASHER, ADAPTOR	1,1		