



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	45	33007	SHAFT, DRIVE - IGNITION DRIVE	1,1		
2		47885A 1	IGNITION DRIVER PILOT ASSEM	1,1		
3		27944	SPRING, HORSESHOE - IGNITION	1,1		
4	17	27962	PIN, ANCHOR - HORSESHOE SPR	1,1		
5		33020	STOP, SPARK ADVANCE - IGNITI	1,1		
6	30	20066	BEARING, BALL - IGNITION DRIV	1,1		
7	10	47910	SCREW, PILOT ASSEMBLY TO IG	4,4		
8		48103A 1	ECONOMIZER COLLAR AND PIN	1,1		
9	17	27961	PIN, ECONOMIZER COLLAR - S	1,1		
10	22	25094	FITTING, GREASE - ECONOMIZEI	1,1		
11		48306	PLATE, THROTTLE ACTUATOR	1,1		
12		46420	SCREW, THROTTLE ACTUATOR	2,2		
13	10	23702	SCREW, ADJUSTING - THROTTL	1,1		
14	11	20645	NUT, THROTTLE ACTUATOR AD	1,1		
15		48039	CAP, THROTTLE ACTUATOR AD.	1,1		
16	12	46246	WASHER, IGNITION DRIVER PILI	1,1		
17		30408	ADAPTOR, IGNITION DRIVER	1,1		
18	22	25094	FITTING, GREASE - IGNITION DR	1,1		
19	10	22040	SCREW, IGNITION DRIVER ADAF	3,3		
20	12	20084	WASHER, IGNITION DRIVER ADA	3,3		
21	11	20083	NUT, IGNITION DRIVER ADAPTO	3,3		
22	12	27939	WASHER, IGNITION DRIVER PILI	1,1		
23	14	27960	TAB WASHER, ADAPTOR CAP FA	1,1		
24	13	27959	WASHER, WAVE-IGNITION DRIV	1,1		
25		27955	CAP, IGNITION DRIVER ADAPTO	1,1		
26	23	29909	SPACER, DRIVE PULLEY	1,1		
27		29906A 1	DRIVEN PULLEY ASSEMBLY	1,1		
28	17	29908	PIN, ROLL - FLANGE LOCATING	1,1		
29		29907	FLANGE, DRIVEN PULLEY	1,1		
30	28	29910	KEY, IGNITION DRIVER	1,1		
31	13	26396	LOCKWASHER, PULLEY CLAMPIN	1,1		
32	10	29911	SCREW, PULLEY CLAMPING (7/1	1,1		
31	12	38832	WASHER, PULLEY CLAMPING SC	1,1		
32	10	49989	SCREW, PULLEY CLAMPING (5/8	1,1		
33		20140	BELT, TIMING	1,1		