



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
	333	3144A 4	IGNITION DRIVER ASSEMBLY, CO	1,1			
1	333	3144	HOUSING, IGNITION DRIVER	1,1			
2	10	47183	SCREW, SET - COIL ASSEMBLY	4,4			
3	333	3172A 1	TERMINAL BOARD ASSEMBLY,	1,1			
4	10	47182	SCREW, TERMINAL BOARD AS	1,1			
5	333	3175	COIL ASSEMBLY, IGNITION DR	1,1			
6	333	3176	COIL ASSEMBLY, IGNITION DRI	1,1			
7	333	3173	HARNESS, PRIMARY CABLE - H	1,1			
8	54	47188	CLAMP, PRIMARY HARNESS C	1,1			
9	10	28259	SCREW, PRIMARY HARNESS C	3,3			
10	30	24998	BEARING, BALL - DRIVER END	1,1			
11	333	3198A 1	SHAFT ASSEMBLY, IGNITION C	1,1			
12	30	49090	BEARING, BALL - IGNITION DRI	1,1			
13	333	3166	CAP, BEARING - IGNITION DRI	1,1			
14	10	47194	SCREW, BEARING CAP FASTEN	3,3			
15	333	3143A 1	ROTOR ASSEMBLY, IGNITION I	1,1			
16	54	47187	CLIP, SPRING - IGNITION DRI	1,1			
17	27	47189	GASKET, IGNITION DRIVER CO	1,1			4
18	333	3141	COVER, IGNITION DRIVER	1,1			
19	10	47185	SCREW, IGNITION DRIVER CO	2,2			
20	14	29157	TAB WASHER, IGNITION DRIV	2,2			
21	22	31521	ELBOW, VENT - IGNITION DRIV	1,1			
22	333	3142A 3	CAP ASSEMBLY, IGNITION DRI	1,1			
23	333	3165A 1	BRUSH AND SPRING ASSEM	1,1			
24	27	47190	GASKET, IGNITION DRIVER CA	1,1			4
25	394	1134A 2	GROUND STRAP ASSEMBLY	1,1			
26	10	47181	SCREW, IGNITION DRIVER CA	3,3			
26	10	47184	SCREW, IGNITION DRIVER CA	1,1			
27	14	29157	TAB WASHER, IGNITION DRIV	4,4			
28	393	3250A 1	LEAD ASSEMBLY, HIGH TENSII	1,1			
--		20121	TERMINAL, HIGH TENSION L	1,1			
--	393	1275	SLEEVE, HIGH TENSION LEA	1,1			
29	25	26547	GROMMET, COIL WIRE BRAC	1,1			
30	332	2854	BOOT, HIGH TENSION LEAD CAE	1,1			
31		47899A 9	SPARK PLUG LEAD ASSEMBLY	4,4		ORDER A-36549A1 KIT FOR REF	
--		20121	CONNECTOR, SPARK PLUG L	4,4			
--	393	1275	SLEEVE, SPARK PLUG LEAD TI	4,4			
32	32	46768	SLEEVE, SPARK PLUG LEAD (6")	2,2			
33	32	26527	SLEEVE, SPARK PLUG LEAD (1	2,2			
34		47604A 1	PROTECTOR ASSEMBLY, SPAF	4,4			
35	22	46288	SLEEVE, HIGH TENSION CABLE	1,1			