



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	19	45307	PLUG, FLYWHEEL PULLER THRE	1		
2	11	22339	NUT, FLYWHEEL	1		
3	12	33001	WASHER, FLYWHEEL NUT	1		
4	28	45554	KEY, FLYWHEEL DRIVE	1		
5	225	2494A13	FLYWHEEL ASSEMBLY, COMPLE	1	SERIAL 00000000-#3076715	
5	225	2494A15	FLYWHEEL ASSEMBLY, COMPLE	1	SERIAL #3149067-09999999	
6	10	32417	SCREW, FLEXIBLE PLATE TO F	8		
7	10	49006	SCREW, PLATE AND HUB TO F	8		
8	17	26618	PIN, DOWEL - PULLEY TO FLY	1		
9		29788	FLANGE, FLYWHEEL PULLEY	1		
10		30306	PULLEY, FLYWHEEL	1		
11		29787	HUB, FLYWHEEL PULLEY	1		
12	398	3618	STATDR, ALTERNATOR	1		
13		30050	TERMINAL, STATOR LEAD WIF	2		
14	10	57021	SCREW, STATOR TO UPPER EN	4		
15	54	22740	CLIP, STATOR LEAD TO UPPER I	1		
16	10	35519	SCREW, STATOR LEAD CLIP FAS	1		
17		22789	"D" WASHER, CLUP FASTENING	1		