



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1128	3367A 1	END CAP ASSEMBLY, UPPER	1		
2	26	29476	OIL SEAL	1		
3	25	31305	"O" RING	1		2,4
4	15	31283A 1	SHIM, UPPER END CAP TO CRAN	AR		
5	10	30225	SCREW, UPPER END CAP MOUN	4		
6	834	3997A 3	CYLINDER BLOCK AND CRANKC.	1		
7	17	20032	DOWEL PIN, CYLINDER BLOCK	2		
8	17	20033	DOWEL PIN, CRANKCASE TO C	2		
9	22	32802	PLUG, PIPE - WATER PRESSUR	1		
10	16	35099	STUD, CARBURETOR MOUNTI	4		
11	16	26133	STUD, CRANKCASE TO DRIVE	2		
12	16	26134	STUD, CYLINDER BLOCK TO D	2		
13	16	48770	STUD, CYLINDER BLOCK TO D	4		*
14	10	26132	SCREW, CRANKCASE TO CYLINC	2		
14	10	32293	SCREW, CRANKCASE TO CYLINC	12		
14	10	33860	SCREW, CRANKCASE TO CYLINC	2		
15	10	33008	SCREW, CRANKCASE AND STAF	2		
16	12	26825	WASHER, CRANKCASE AND STA	2		
17		26551	BRACKET, GROUND STRAP TO (	1		
18	10	26548	SCREW, GROUND STRAP TO BF	1		
19	12	20084	WASHER, GROUND STRAP AND	1		
20	11	46793	NUT, CRANKCASE TO CYLINDER	18		
21	10	53904	SCREW, MAIN BEARING LOCKIN	2		
22	14	20091	TAB WASHER, BEARING LOCKIN	3		
23	10	20359	SCREW, CENTER MAIN BEARING	1		
24	1126	3369A 2	END CAP ASSEMBLY, LOWER	1		
25	21	56011A 1	CHECK VALVE ASSEMBLY, ENCI	1		
26	26	29476	OIL SEAL, UPPER	2		
27	25	20081	"O" RING	1		2,4
28	15	20085A 1	SHIM, LOWER END CAP (.002-3-E	AR		
29	10	30225	SCREW, LOWER END CAP MOUN	3		
30	32	33729	TUBE, BALANCE - MAIN BEARING	1		
31	22	25885	ELBOW, BALANCE TUBE TO MAI	1		
32	54	20386	CLAMP, BALANCE TUBE TO ELB	2		
32	54	20387	CLAMP, LOWER BLEED HOSE	2		
33	22	53491	TEE, BLEED AND BALANCE HOS	1		
34	32	52742A 1	HOSE, CYLINDER BLEED - LOWE	1		
35	27	37449	GASKET, CYLINDER BLOCK TO E	1		2,4
36		37447	PLATE, BAFFLE PLATE TO MANIF	1		
37	27	37414	GASKET, BAFFLE PLATE TO MAN	1		2,4
38		46288	COVER, EXHAUST MANIFOLD	1		