



			Parts List			
Ref	Class	Part	Description	Qty	Comment	Footnote
1		60117	BRACKET, COWL SUPPORT - TO	1		
2		62444	SEAL, RUBBER - TOP BRACKET	2		
3	10	60300	SCREW, TOP COWL BRACKET A	4		
4	11	46887	NUT, SUPPORT BRACKET ATTACH	4		
5		62501A	SHIELD ASSEMBLY, FLYWHEEL	1		
6	10	48409	SCREW, SHIELD TO TOP SUPPOR	3		
7	10	30663	SCREW, SHIELD TO TOP SUPPOR	1		
8		60112	BRACKET, COWL SUPPORT - RE	1		
9		60299	RETAINER, SPARK PLUG LEADS	3		
10	10	31206	SCREW, RETAINER TO REAR SL	3		
11		63007	MOUNT, RUBBER - BRACE TO RI	1		
12	12	20346	WASHER, RUBBER MOUNT TO F	2		
13	11	20361	NUT, RUBBER MOUNT TO REAR	2		
14		60116	BRACE, REAR COWL SUPPORT I	1		
15		49651A	GROUND STRAP ASSY BRACE T	1		
16	10	24644	SCREW, SUPPORT BRACKET BF	3		
17	11	46887	NUT, SUPPORT BRACKET BRAC	3		
18		60111	BRACKET, COWL SUPPORT (FRC	1		
19		61344	RETAINER, WIRING HARNESS A	1		
20	10	35519	SCREW, RETAINER TO FRONT S	2		
21		63007	MOUNT, RUBBER - FRONT SUPP	1		
22	12	20346	WASHER, RUBBER MOUNT TO F	2		
23	11	20361	NUT, RUBBER MOUNT TO FRON	2		
24		63007	MOUNT, RUBBER - FRONT SUPP	1		
25		49651A	GROUND STRAP ASSEMBLY, FR	1		
26	12	20346	WASHER, RUBBER MOUNT ATT	2		
27	11	20361	NUT, RUBBER MOUNT ATTACHI	2		
28	26	60296	SEAL, FUEL CONNECTOR - FRON	1		
29		62391	BLANKET, SOUND - FRONT SUPP	1		
30		62219	DRIP TRAY, FRONT SUPPORT B	1		
31		62869	BLANKET, SOUND - DRIP TRAY	1		
32	32	52742A	HOSE, DRIP TRAY TO REAR SUF	1		
33	10	35519	SCREW, DRIP TRAY TO FRONT	3		
34	54	22740	CLP, HOSE TO REAR SUPPORT I	1		
35	10	31206	SCREW, HOSE CLIP FASTENING	1		
36		22789	"D" WASHER, CLIP FASTENING	1		
34	54	22875	CLIP, HOSE TO EXHAUST PLATE	1		
35	10	31206	SCREW, HOSE CLIP FASTENING	1		
36		22789	"D" WASHER, CLIP FASTENING	1		
37		60113	PLATE, FRONT COVER MOUNTIN	1		
38		60312	LATCH, FRONT COVER ATTACH	1		