



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	450	4393A 2	CRANKSHAFT ASSEMBLY	1	
2	30	54816	BEARING, BALL - UPPER	1	
3	30	54816	BEARING, BALL - LOWER	1	
4	15	22369A 1	SHIM, LOWER BEARING TO CRA	AR	
5		60834A 1	CARRIER ASSEMBLY, "O" RING	1	
6	25	35276	"O" RING, CARRIER	1	4
7	542	4846A 1	MAIN BEARING ASSEMBLY (VAL)	2	
8	17	20032	DOWEL PIN, MAIN BEARING	4	
9	17	60282	DOWEL PIN (STEPPED)	2	
10	17	55453	DOWEL PIN, REED STOP	16	
11	34	60281A 1	REED SET, MATCHED - MAIN B	2	
12	34	60318	REED STOP	8	
13	10	53481	SCREW, REED STOP MOUNTING	8	
14	11	20110	NUT, REED STOP MOUNTING :	8	
15	10	45775	SCREW, MAIN BEARING CLAM	4	
16	11	45774	NUT, MAIN BEARING SCREW C	4	
17		26113	RACE, OUTER (PAIR)	2	
18	53	26933	RING, SNAP - OUTER RACE C	2	
19	29	48410	BEARING, NEEDLE	112	
20	745	4891A 2	PISTON AND PISTON PIN ASSEM	3	
21	40	52035	LOCK RING, PISTON PIN	6	
22	39	45155A12	RING, PISTON	1	
23	622	4850A 4	CONNECTING ROD AND CAP AS:	3	
24	10	54803	SCREW, CAP TO CONNECTING	6	
25	11	49091	NUT, CONNECTING ROD SCRE	6	
26	31	63075A 1	BEARING ASSEMBLY, CRANKP	3	
27	29	47270	BEARING, NEEDLE - PISTON PI	87	
28	12	47247	WASHER, NEEDLE LOCATING	6	
--	745	4881A 1	PISTON AND PISTON PIN ASSEM	3	
--	39	45204A12	RING, PISTON (.015)	1	