



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	855	4553A 3	CYLINDER BLOCK AND CRANK	1		
2	27	60286	GASKET, CRANKCASE TO CYLI	2		4
3	16	21831	STUD, CARBURETOR MOUNTI	4		
4	16	30715	STUD, CRANKCASE TO DRIVE	2		
5	17	20033	DOWEL PIN, CRANKCASE TO C	2		
6	17	20323	DOWEL PIN, CYLINDER BLOCK	2		
7	16	20984	STUD, CYLINDER BLOCK TO D	2		
8	16	29589	STUD, CYLINDER BLOCK TO D	1		
8	16	20983	STUD, CYLINDER BLOCK TO D	1		
9		57854	RESTRICTION, CYLINDER BLEI	2		
10		60115	COVER, STARTER MOTOR TO	1		
11	10	26132	SCREW, STARTER MOTOR CO	1		
12	11	46793	NUT, STARTER MOTOR COVE	1		
13	10	57841	SCREW, STARTER MOTOR CO	1		
14	13	26393	LOCKWASHER, STARTER MOT	1		
15	22	32802	PIPE PLUG, CRANKCASE	1		
16		58906	COVER, STARTER MOTOR TO	1		
17	10	33860	SCREW, STARTER MOTOR CO	1		
18	10	26132	SCREW, STARTER MOTOR CO	1		
19	11	46793	NUT, STARTER MOTOR COVE	2		
20	10	57233	SCREW, CRANKCASE TO CYLIN	2		
21	10	29942	SCREW, CRANKCASE TO CYLIN	7		
22	10	22039	SCREW, CRANKCASE TO CYLIN	4		
23	12	26020	WASHER, CRANKCASE TO CYLIN	13		
24	11	46793	NUT, CRANKCASE TO CYLINDEF	13		
25		62397	INDICATOR, TIMING	1		
26	1143	4390A 1	END CAP ASSEMBLY UPPER	1		
27	25	47254	"O" RING, END CAP	1		4
28	21	56011A 2	CHECK VALVE ASSEMBLY, ENC	1		
29	26	29476	OIL SEAL, END CAP	1		
30	10	30225	SCREW, UPPER END CAP MOUN	4		
31	15	47248A 1	SHIM, UPPER END CAP (.006-8-1)	AR		
32	1144	4888A 1	END CAP ASSEMBLY, LOWER	1		
33	25	32546	"O" RING, END CAP	1		
34	26	29476	OIL SEAL, END CAP	2		
35	21	56011A 2	CHECK VALVE ASSEMBLY, ENC	3		
36	10	30225	SCREW, LOWER END CAP MOUN	3		
37	15	20085A 1	SHIM, LOWER END CAP (.002-3-E	AR		
38		58910	COVER, TRANSFER PASSAGE	1		
39	27	60311	GASKET, TRANSFER PASSAGE C	1		4
40	10	28827	SCREW, TRANSFER PASSAGE C	8		