



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		62973A 4	FUEL PUMP ASSEMBLY	1	
2	21	30430A 3	CHECK VALVE ASSEMBLY	1	
3		55278A 1	DIAPHRAGM KIT	1	3
4			GASKET, CHECK VALVE TO	2	3
5			GASKET, FUEL PUMP	2	3
6		23004	RETAINER, CHECK VALVE	1	
7	10	68789	SCREW, RETAINER TO HOUSII	2	
8	10	35581	SCREW, PUMP MOUNTING (1 5/8	3	
9	22	32802	PLUG, PIPE - FUEL PUMP	1	
10	32	71121	HOSE ASSEMBLY, FUEL PUMP T	1	
11	22	25885	ELBOW, HOSE TO EXHAUST PL	1	
12	32	71121	HOSE ASSEMBLY, FUEL PUMP T	1	
13	54	68725	CLAMP, HOSE TO FUEL PUMP AT	4	
14		69555	NOZZLE, TELL TALE - REAR SUF	1	
15	54	70705	CLAMP, TELL TALE NOZZLE	1	
16	10	30663	SCREW, TELL TALE CLAMP	2	
17	54	47483	CLAMP, TELL TALE HOSE TO EX	3	
18	12	29626	WASHER, CLAMP SCREW	2	
19	22	64705	FITTING, FUEL PUMP (INLET)	1	
20	32	70432	FUEL LINE, ADAPTOR TO FUEL F	1	
21	54	68424	CLAMP, FUEL LINE ATTACHING	6	
22	22	71909	FITTING, FUEL LINE TO ADAPTO	1	
23		22833	ADAPTOR, CHECK UNIT (FUEL P	1	
24		23069	STEM, CHECK UNIT ADAPTOR	1	
25	25	20415	"O" RING, ADAPTOR STEM	1	3
26	24	23067	SPRING, ADAPTOR STEM	1	
27		30188	CUP WASHER, ADAPTOR	1	
28	10	36154	SCREW, ADAPTOR TO FRONT S	2	
29	11	46887	NUT, ADAPTOR FASTENING SCF	2	
30	32	65424A 1	FUEL LINE ASSEMBLY, FUEL PUI	1	
31		58907	HOUSING, FUEL FILTER AND CO	1	
32	10	69092	SCREW, FILTER HOUSING TO TI	2	
33	12	34437	WASHER, FUEL FILTER HOUSIN	2	
34	27	25851	GASKET, FILTER COVER (BOTTC	1	3
35	1399	3938	FILTER, FUEL	1	
36	27	25849	GASKET, FILTER COVER (TOP)	1	3
37	1399	3690	COVER, FUEL STRAINER	1	
38	10	25822	SCREW, FILTER COVER FASTEN	1	
39	27	25848	GASKET, FILTER COVER FASTEN	1	3
40	22	70007	FITTING, FUEL STRAINER COVER	1	
41	22	62146	FUEL LINE, COVER TO UPPER C	1	