



			Parts List			
Ref	Class	Part	Description	Qty	Comment	Footnote
1		73641A	BRACKET, COWL SUPPORT-TOP	1		
2		62444	SEAL, RUBBER-TOP BRACKET A	2		
3		76263	CLIP, TOP COWL SUPPORT BRA	1		
4	10	48408	SCREW, CLIP TO TOP COWL SUI	1		
5	12	45075	WASHER, CLIP TO TOP COWL SI	AR		
6		76219	SHIELD FLYWHEEL	1		
7	10	37656	SCREW, SHIELD TO TOP SUPPO	1		
8	10	48408	SCREW, SHIELD TO TOP SUPPO	3		
9		74510A	BRACKET, COWL SUPPORT-REA	1		
10		69876	SEAL, REAR BRACKET AND TOP	4		
11		63007	MOUNT, RUBBER-BRACE TO RE.	1		
12	12	20346	WASHER, RUBBER MOUNT TO F	2		
13	11	35045	NUT, RUBBER MOUNT TO REAR	2		
14		26901	STOP, RUBBER-REAR SUPPORT	2		
15		60116	BRACE, REAR COWL SUPPORT I	1		
16	10	24878	SCREW, SUPPORT BRK. BRACE	3		
17		63007	MOUNT, RUBBER- FRONT SUPP	1		
18	12	20346	WASHER, RUBBER MOUNT TO F	2		
19	11	20361	NUT, RUBBER MOUNT TO FRON	2		
20		71097	BRACKET, RUBBER MOUNT	1		
21	10	39349	SCREW, BRACKET TO CRANKCA	1		
22		73625	ATTENUATOR, SOUND	1		
23		76218	COVER, TOP-SOUND ATTENUAT	1		
24	27	71096	GASKET, TOP COVER	1		
25	10	37571	SCREW, TOP COVER TO SOUND	2		
26	12	56681	WASHER, TOP COVER SCREW	2		
27		75841	COVER, MANUAL CHOKE	1		
28	10	37978	SCREW, COVER TO TOP COVER	4		
29	12	56681	WASHER, COVER SCREW	4		
30		73986	AIR MANIFOLD	1		
31	10	34633	SCREW, AIR MANIFOLD TO SOU	2		
32	12	38753	WASHER, AIR MANIFOLD SCREW	2		
34		63007	MOUNT, RUBBER-FRONT SUPP	1		
36	12	20346	WASHER, RUBBER MOUNT ATT.	2		
37	11	20361	NUT, RUBBER MOUNT ATTACHI	2		
38	26	60296	SEAL, FUEL CONNECTOR-FRON	1		
39	22	65670A	CONNECTOR ASSEMBLY, ATTEN	1		
40	32	54936	TUBE, VENT (LOWER)	1		
41	22	65857	FITTING, CRANKCASE VENT (PR	1		
42		72956	COVER, SOUND ATTENUATOR (I	1		
43	27	76192	GASKET, FRONT COVER	1		