



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	1623	2460A24	GEAR HOUSING ASSEMBLY, COM	1,1	
-	1623	2460A25	GEAR HOUSING ASSEMBLY, COM	1,1	
1	1623	2460A20	GEAR HOUSING ASSEMBLY	1,1	2
2	16	45199	STUD, GEAR HOUSING TO D	1,1	2
3	16	45198	STUD, GEAR HOUSING TO D	2,2	2
4	16	36292	STUD, WATER PUMP BASE A	1,1	2
5	16	37435	STUD, WATER PUMP BASE A	2,2	2,0
6	31	32898	BEARING, ROLLER - DRIVE S	1,1	
7	45	38459	DRIVE SHAFT(SHORT SHAFT)	1,1	
7	45	38460	DRIVE SHAFT(LONG SHAFT)	1,1	
8	43	31419	GEAR, PINION - DRIVE SHAFT	1,1	
9	11	30932	NUT, PINION GEAR TO DRIVE	1,1	
10	15	30278A 1	SHIM, DRIVE SHAFT BALL BEA	AR,AR	
11	30	20464	BEARING, BALL - DRIVE SHAFT	1,1	
12	53	30726	RING, RETAINING - BALL BEA	1,1	
10	15	30278A 1	SHIM, WATER PUMP BASE TO	AR,AR	
13	27	32438	GASKET, WATER PUMP BASE	1,1	4
14	25	30224	"O" RING, WATER PUMP BASE	1,1	4
15	46	38931A 1	WATER PUMP BASE ASSEMBL	1,1	
16	26	31489	OIL SEAL, WATER PUMP BAS	1,1	
17	26	31507	OIL SEAL, WATER PUMP BAS	1,1	
18	17	35973	DOWEL PIN, WATER PUMP E	2,2	
19	27	32433	GASKET, LOWER - WATER PUI	1,1	4
20		32435	PLATE, FACE - WATER PUMP E	1,1	
21	27	32434	GASKET, UPPER - FACE PLATE	1,1	4
22	46	37433A 1	WATER PUMP BODY ASSEMBL	1,1	
23		30915	INSERT, WATER PUMP BODY	1,1	
24	26	31507	OIL SEAL, WATER PUMP BOC	1,1	
26	26	38970	SEAL, RUBBER - WATER INLI	1,1	
27	47	30221	IMPELLER, WATER PUMP	1,1	
28	17	29967	PIN, IMPELLER DRIVE	1,1	
29	10	30720	SCREW, WATER PUMP BODY	1,1	
30	13	26992	LOCKWASHER, WATER PUMP	3,3	
31	11	29598	NUT, WATER PUMP BODY FAS	2,2	
32	13	26993	LOCKWASHER, WATER PUMP	1,1	
33	11	28770	NUT, WATER PUMP BODY FAS	1,1	
34	25	30271	RING, RUBBER - CENTRIFUGAI	1,1	4
35	23	29804	SLEEVE, GUIDE - WATER INLE	1,1	
36	25	30613	"O" RING, UPPER - DRIVE SHA	1,1	4
37		37641	SEAL, EXHAUST TUBE	1,1	4
38		28051	PLATE, SUPPORT - EXHAUST	1,1	