



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		56677A 4	FUEL PUMP ASSEMBLY	1		
2	21	30430A 4	CHECK VALVE ASSEMBLY	1		
3		56678A 1	DIAPHRAGM KIT	1		2,4
4			GASKET, FUEL PUMP COVE	1		2,4
5			GASKET, FUEL PUMP	2		2,4
6			GASKET, CHECK VALVE TO	2		2,4
7		23004	RETAINER, CHECK VALVE	1		
8	10	20037	SCREW, RETAINER TO HOUSI	2		
9		56680	COVER, FUEL PUMP	1		
10	10	38036	SCREW, PUMP MOUNTING (1 1/	1		
11	10	30273	SCREW, PUMP MOUNTING (1 7/	2		
12	32	33154A 1	FUEL LINE ASSY, PUMP TO CAR	1		
13	22	29085	ELBOW (45 ), CARBURETOR	1		
14	22	30174	ELBOW, FUEL PUMP OUTLET	1		
15	22	30175	SLEEVE, FUEL PUMP OUTLET EL	1		
16	22	30177	NUT, FUEL PUMP OUTLET ELBO	1		
17	32	30176	FUEL LINE, ADAPTOR TO FUEL F	1		
18	22	30468	CONNECTOR, FUEL INLET	1		
19	22	30175	SLEEVE, FUEL PUMP INLET ELBI	1		
20	22	30177	NUT, FUEL PUMP INLET ELBOW	1		
21		30186	ADAPTOR, CHECK UNIT (FUEL LI	1		
22		30187	STEM, CHECK UNIT ADAPTOR	1		
23	25	20415	"O" RING, ADAPTOR STEM	1		2,4
24	24	30189	SPRING, ADAPTOR STEM	1		
25		30188	CUP WASHER, ADAPTOR	1		
26	10	37561	SCREW, ADAPTOR TO BOTTOM	1		
26	10	37990	SCREW, ADAPTOR TO BOTTOM	1		
27	11	46887	NUT, ADAPTOR FASTENING SCF	2		
28	32	31550A 1	FUEL LINE ASSY, UPPER TO LO	1		