



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
	1630	7360A12	GEAR HOUSING ASSEMBLY (SHI	1	UNITED STATES 5306000 AND I	
	1630	7360A13	GEAR HOUSING ASSEMBLY (LOP	1	UNITED STATES 5306000 AND I	
	1630	7360A29	GEAR HOUSING ASSEMBLY (SHI	1	UNITED STATES 530601 AND U	
	1630	7360A30	GEAR HOUSING ASSEMBLY (LOP	1	UNITED STATES 530601 AND U	
1	1630	7360A11	GEAR HOUSING ASSEMBLY	1		
36	10	79953	SCREW, GREASE FILLER HOLE	1		
37	12	20260	WASHER, GREASE FILLER HOI	1		
38	10	28653	SCREW, VENT HOLE	1		
39	12	20262	WASHER, VENT HOLE SCREW	1		
40		71659A	SHIFT SHAFT ASSEMBLY (SHO	1		
40		71658A	SHIFT SHAFT ASSEMBLY (LON	1		
41	53	22899	RETAINING RING, SHIFT SHA	1		
42	23	30676A	BUSHING ASSEMBLY, SHIFT SI	1		
43	25	26802	"O" RING, SHIFT SHAFT BUS	1		3
44	26	30696	OIL SEAL, SHIFT SHAFT BUSI	1		
45	10	39149	SCREW, SHIFT SHAFT BUSHIN	1		
46		44434	CAM, SHIFT	1		
47	15	30522A	SHIM ASSEMBLY, BALL BEARIN	AR		4
48	30	21889	BALL BEARING, FOWARD GEAR	1		
49	43	48577A	FORWARD GEAR	1		
50	31	22458	ROLLER BEARING, FORWAR	1		
51	52	63314	RATCHET, SLIDING CLUTCH	1		
52	17	30535	CROSS PIN, RATCHET TO PRO	1		
53	53	32449	RETAINING RING, CROSS PIN	1		
54		31334	FOLLOWER, SHIFT CAM	1		
55	24	76298	SPRING, COMPRESSION - CAM	1		
56	44	75667A	PROELLER SHAFT	1		
57	43	63316	REVERSE GEAR	1		
58	15	30532A	SHIM ASSEMBLY, THRUST WA	AR		4
59		71479	SLEEVE, THRUST - REVERSE	1		
60	30	21889	BALL BEARING, REVERSE GEA	1		
61	25	30529	"O" RING, BEARING CARRIER	1		3
62		72673A	BEARING CARRIER ASSEMBLY	1		
63	31	22458	ROLLER BEARING, BEARING	1		
64	26	66022	OIL SEAL, BEARING CARRIEF	1		
65		86236	COVER, GEAR HOUSING	1		
66		86665A	COLLAR, PROPELLER GUIDE	1		
67	48	87572A10	PROPELLER (SHIPPED WITH EN	1		
67	48	47922A10	PROPELLER	OPT	(9" DIA., PITCH, 2 BLADES, ALU	8
67	48	47926A10	PROPELLER	OPT	(9" DIA., 10" PITCH, 2 BLADES, /	8
67	48	47920A10	PROPELLER (SHIPPED WITH EN	OPT		8