



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1471	7324A 1	SWIVEL BRACKET ASSEMBLY	1		
2	22	74036	GREASE FITTING, SWIVEL BRACKET	3		
3	23	64028	BUSHING, SWIVEL BRACKET	2		
4		77334	PLATE, CO-PILOT	1		
5	10	78038	SCREW, CO-PILOT PLATE, TO SWIVEL BRACKET	3		
6		72845A 1	PLATE ASSEMBLY, CLAMP - CO-FITTING	1		
7		20203	DISC, FRICTION	4	CLAMP PLATE AND SWIVEL BRACKET	
8	10	36154	SCREW, CLAMP PLATE ADJUSTING	1		
9	212	35462	WASHER, CLAMP PLATE ADJUSTING	1		
10	17	25319	ROLL PIN, SPRING GUIDE	1		
11		87984A 1	LEVER ASSEMBLY	1	TILT STOP (87984-1 USED ON 1	
12	10	41433	SCREW, TILT STOP LEVER	2		
13	13	31030	WASHER, WAVE - LEVER ANCHOR	1		
14	11	20361	NUT, TILT STOP LEVER SCREW	2		
15		72794	STOP, REVERSE LOCK	1		
16	10	71056	SCREW, REVERSE STOP TO SWIVEL BRACKET	1		
17	13	26992	LOCKWASHER, REVERSE STOP	1		
18	12	71055	WASHER, REVERSE STOP SCREW	1		
19		63554	GUIDE, SPRING	1		
20		79744	LEVER, CONTROL - TROLL BRACKET	1		
21	13	63631	WAVE WASHER, TROLL BRACKET	1		
22		71419	ROD, REVERSE LOCK TO SWIVEL BRACKET	1		
23	23	26841	BUSHING, NYLON - REVERSE LOCK	2		
24	18	45882	COTTER PIN, REVERSE LOCK LEVER	1		
25		63628	LEVER, REVERSE LOCK	1		
26		61007	RETAINER, ROD - REVERSE LOCK	1		
27		63559	BRACKET, TROLL	1		
28	24	63630	SPRING, EXTENSION - TROLL BRACKET	1		
29		66559	TUBE, SWIVEL BRACKET TO SWIVEL BRACKET	1		