



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
1	1471	7324A 1	SWIVEL BRACKET ASSEMBLY	1			
2	22	74036	GREASE FITTING, SWIVEL BRACKET	3			
3	23	64028	BUSHING, SWIVEL BRACKET	2			
4		77334	PLATE, CO-PILOT	1			
5	10	78038	SCREW, CO-PILOT PLATE, TO SWIVEL BRACKET	3			
6		72845A 1	PLATE ASSEMBLY, CLAMP - CO-PILOT	1			
7		20203	DISC, FRICTION	4	CLAMP PLATE AND SWIVEL BRACKET		
8	10	36154	SCREW, CLAMP PLATE ADJUSTMENT	1			
9	212	35462	WASHER, CLAMP PLATE ADJUSTMENT	1			
10	17	25319	ROLL PIN, SPRING GUIDE	1			
11		87984A 1	LEVER ASSEMBLY	1	TILT STOP (87984-1 USED ON 1		
12	10	41433	SCREW, TILT STOP LEVER	2			
13	13	31030	WASHER, WAVE - LEVER ANCHOR	1			
14	11	20361	NUT, TILT STOP LEVER SCREW	2			
15		72794	STOP, REVERSE LOCK	1			
16	10	71056	SCREW, REVERSE STOP TO SWIVEL BRACKET	1			
17	13	26992	LOCKWASHER, REVERSE STOP	1			
18	12	71055	WASHER, REVERSE STOP SCREW	1			
19		63554	GUIDE, SPRING	1			
20		79744	LEVER, CONTROL - TROLL BRACKET	1			
21	13	63631	WAVE WASHER, TROLL BRACKET	1			
22		71419	ROD, REVERSE LOCK TO SWIVEL BRACKET	1			
23	23	26841	BUSHING, NYLON - REVERSE LOCK	2			
24	18	45882	COTTER PIN, REVERSE LOCK LEVER	1			
25		63628	LEVER, REVERSE LOCK	1			
26		61007	RETAINER, ROD - REVERSE LOCK	1			
27		63559	BRACKET, TROLL	1			
28	24	63630	SPRING, EXTENSION - TROLL BRACKET	1			
29		66559	TUBE, SWIVEL BRACKET TO SWIVEL BRACKET	1			