



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	19	45907	PLUG, FLYWHEEL	1		
2		42956A	COVER ASSEMBLY, FLYWHEEL	1		
3		79022	MARKER, TIMING	1		
4	10	37572	SCREW, TIMING MARKER	2		
5	12	72761	WASHER, TIMING MARKER SC	2		
6	11	42979	NUT, FLYWHEEL	1		
7	12	68229	WASHER, FLYWHEEL	1		
8	261	9008A16	FLYWHEEL ASSEMBLY	1		
9	398	8778A10	STATOR ASSEMBLY	1		
10	10	40073 25	SCREW, STATOR	4		
11		99021A 3	TRIGGER ASSEMBLY	1		
12	50	66015	STARTER MOTOR	1		
13		56703	COLLAR, STARTER MOTOR	2		
14		57247	STOP, RUBBER-STARTER MOTC	2		
15	84	93388A 1	WIRE, STARTER MOTOR TO PL	1		
16	10	69035	SCREW, WIRE TO STARTER MO	1		
17	84	88439A20	WIRE, STARTER MOTOR (BLACK	1		
18	13	26992	LOCKWASHER, STARTER MOTO	1		
19	11	64015	NUT, STARTER MOTOR TERMIN	1		