



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1255	8627A 5	OIL TANK	1		
2		99160	BOOT, OIL TANK (UPPER)	1		
3	87	44452A 1	TEST SWITCH ASSEMBLY	1		
4		44437	COVER, TEST SWITCH	1		
5		98895	BRACKET, OIL TANK (UPPER)	1		
6	10	40094 30	SCREW, OIL TANK BRACKET	2		
7	36	42653A 2	CAP ASSEMBLY, OIL TANK	1		
8	27	42999	GASKET, CAP	1		
9		93254	SWIVEL BASE	1		
10		93421	SWIVEL BALL	1		
11		43359	COWL ROD	1		
12	54	43406	CAMP, COWL ROD	1		
13	10	26548	SCREW, CLAMP	1		
14	12	22887	WASHER, CLAMP SCREW	1		
15	10	12896	SCREW, SWITCH	1		
16	87	12886A 2	SWITCH ASSEMBLY, OIL TANK	1		
17		99161	BOOT, OIL TANK BASE	1		
18		42888	BASE, OIL TANK	1		
19	25	56291	GROMMET	1		
20	10	40113 50	SCREW, BASE	2		
21	32	43017 36	TUBING	3		
22	22	73318	TEE	1		
23		73498	STA-STRAP	AR		7
24		42959T	OIL PUMP	1		
25	25	62705	"O" RING, OIL PUMP	2		10
26		42945A 1	ADAPTOR ASSEMBLY, OIL PUMF	1		
27	43	43020 1	DRIVEN GEAR	1		
28	10	40093 40	SCREW, OIL PUMP	2		
29	32	43016 19	TUBING, OIL PUMP TO FUEL PUM	1		
-	27	43004A86	GASKET SET			