



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		42954A	1 PLATE ASSEMBLY, EXHAUST	1	
2	17	23784	DOWEL PIN	4	
3		42939	SEAL, LOWER COWL	1	
4		42949	1 MOUNT, UPPER (LONG)	1	
4		44344	1 MOUNT, UPPER (X-LONG)	1	
5	10	40113	50 SCREW, UPPER MOUNT TO EXH-	4	
6	10	42974	SCREW, UPPER MOUNT	2	
6	10	12515	SCREW, UPPER MOUNT (HANDL	2	
7	12	93416	WASHER, UPPER MOUNT SCRE	2	
8	12	28421	WASHER, UPPER MOUNT SCRE	2	
9	11	90099	NUT, UPPER MOUNT SCREW	2	
10	22	99664	ELBOW, EXHAUSE PLATE	1	
11	10	40111	35 SCREW, EXHAUSE PLATE	2	
11	10	40107	70 SCREW, EXHAUSE PLATE	1	
12	27	43008	GASKET, EXHAUST PLATE	1	10
13		42966T	EXHAUST TUBE	1	
14	10	40107	35 SCREW, EXHAUST TUBE TO PL	6	
15		42962	SEAL, EXHAUST TUBE	1	
16	32	43014	1 WATER TUBE (LONG)	1	
16	32	43014	2 WATER TUBE (X-LONG)	1	
17		99019	CLAMP, WATER TUBE SEAL	1	
18		42941	SEAL, WATER TUBE (UPPER)	1	10
19	10	40107	50 SCREW, CLAMP	2	
20	25	93221	GROMMET, WATER TUBE	1	10
21		42953A	1 BRACKET ASSEMBLY, COWL (LO	1	
22		43405	SEAL, LOWER COWL BRACKET	1	
23	10	40095	55 SCREW, LOWER COWL BRACKE	3	
24	23	48237	BUSHING, SHIFT SHAFT	1	
25		79932A	9 SHIFT SHAFT ASSEMBLY (UPPE	1	
26	23	42994	BUSHING, SHIFT SHAFT	1	
27		42912	1 SHIFT LINK	1	
28	13	29720	WAVE WASHER, SHIFT SHAFT	1	
29	12	24664	WASHER, SHIFT SHAFT	1	
30	11	40063	4 NUT, SHIFT SHAFT	1	
31	23	43041	SPACER, SHIFT SHAFT (LONG)	1	
31	23	11289	SPACER, SHIFT SHAFT (X-LONG)	1	
32		43053	COUPLING, SHIFT SHAFT (NON F	1	
33		43585	COUPLING, SHIFT SHAFT (POWE	1	
.	27	43004A86	GASKET SET		