



15164

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		42954A 3	PLATE ASSEMBLY, Exhaust	1		
2	17	23784	PIN, Dowel	5		
3		42939	SEAL, Lower Cowl	1		
4		42949 1	MOUNT, (3.25 Inch), Upper	1		
4		42949 2	MOUNT, (2.375 Inch), Upper	1		
4		44344 1	MOUNT, (3.25 Inch), Upper	1	(Commercial)	
4		44344 2	MOUNT, (2.375 Inch), Upper	1	(Commercial)	
5	10	40095 50	SCREW, Upper Mount To Exhaust	4		
6	10	42974	BOLT, (M12 x 175), Upper Mount	2		
6	10	12515	SCREW, Upper Mount, Handle Mo	2		
7	12	93416	WASHER, Upper Mount Screw	2		
8	12	28421	WASHER, Upper Mount Screw	2		
9	11	90099	NUT, Upper Mount Screw	2		
10	22	99664	ELBOW, Exhaust Plate	1		
11	10	40107 35	SCREW, (M8 x 35), Exhaust Plate	2		
11	10	40107 70	SCREW, (M8 x 70), Exhaust Plate	1		
12	27	43008 3	GASKET, Exhaust Plate	1	(Contents Of (27-43004A86) Gask	1
13		42966T 1	EXHAUST TUBE	1		
13		814128 2	EXHAUST TUBE	1	(90 - Use With WME-15 Carburet	
14	10	40107 35	SCREW, (M8 x 35), Exhaust Tube	6		
15		42962	SEAL, Exhaust Tube	1		
16	32	43014 1	WATER TUBE, Long	1		
16	32	43014 2	WATER TUBE, X-Long	1		
17		99019	CLAMP, Water Tube Seal	1		
18		42941	SEAL, Water Tube, Upper	1		1
19	10	40107 50	SCREW, (M8 x 50), Clamp	2		
20	25	93221	GROMMET, Water Tube	1	(Contents Of (27-43004A86) Gask	1
21		42953A 2	BRACKET ASSEMBLY, Cowl, Low	1		
21		42953A 3	BRACKET ASSEMBLY, Cowl, Low	1		
21		42953A 4	BRACKET ASSEMBLY, Cowl, Low	1		
22		43405	SEAL, Lower, Cowl, Bracket	1		
23	10	40095 55	SCREW, Lower Cowl Bracket	3		
24	23	48237	BUSHING, Shift Shaft	1		
25		79932A 9	SHIFT SHAFT ASSEMBLY, Upper	1		
26	23	42994	BUSHING, Shift Shaft	1		
27		42912 1	SHIFT LINK	1		
28	13	29720	WASHER, Wave, Shift Shaft	1		
29	12	24664	WASHER, Shift Shaft	1		
30	11	40063 4	NUT, (M6), Shift Shaft	1		
31	23	43041	SPACER, Shift Shaft, Long	1		
31	23	11289	SPACER, Shift Shaft, X-Long	1		