



15155

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		42946	LEVER, Throttle	1		
2	10	42977	SCREW, Adjusting	1		
3	11	40020 1	NUT, (M5), Jam, Adjusting Screw	1		
4		42947	LEVER, Spark Advance	1		
5	10	42978	SCREW, Adjusting	2		
6	11	40020 2	NUT, Jam, Adjusting Screw	2		
7		42942	CAP, Nylon, Adjusting	2		
8	16	42986	STUD, Levers	1		
9	24	55162	SPRING, Throttle/Spark Advance	1		
10	23	42992	BUSHING, Lever Stud	1		
11	12	42980	WASHER, Lever Stud	1		
12	11	90517	NUT, (M10), Lever Stud	1		
13		42927	INSERT, Throttle Lever	1		
14	12	35459	WASHER, Throttle Lever Pin	1		
15	11	40063 4	NUT, (M6), Throttle Lever Pin	1		
16		42918	ROD, Spark Advance	1		
17		93254	SWIVEL BASE	2		
18		93421	SWIVEL BALL	2		
19		42919	ROD, Throttle	1		
20	24	14159	SPRING, Cam Return	1		
21	23	93248	BUSHING, Swivel	2		
22		42948T	CAM, Throttle	1		
23	16	42984	STUD, Throttle Cam	1		
24	12	69056	WASHER, (.255 x .620 x .03), Thro	1		
25	11	40063 4	NUT, (M6), Throttle Cam Stud	1		