



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1592	7512A10	DRIVE SHAFT HOUSING ASSEM	1		
1	1593	7513A12	DRIVE SHAFT HOUSING ASSEM	1		
2	19	64649	PLUG, PLASTIC-TRIM TAB SCR	1		
3	16	57932	STUD, DRIVE SHAFT HOUSING	1		
4	16	57935	STUD, DRIVE SHAFT HOUSING	1		
5	12	65791	WASHER, GEAR HOUSING STUC	2		
6	11	34933	NUT, GEAR HOUSING STUDS (7,	2		
7		93445	MOUNT, RUBBER-UPPER	2		
8		96401	SEAL, UPPER MOUNT	2		
9	12	27727	WASHER, UPPER MOUNT BOLT	2		
10	12	66966	WASHER, RUBBER-UPPER MOU	2		
11	12	30514	WASHER, UPPER MOUNT BOLT	2		
12	11	35933	NUT, UPPER MOUNT BOLT	2		
13		87883	COVER, UPPER MOUNT	2		
14	10	76630	SCREW, UPPER MOUNT COVER	4		
15	12	29245	WASHER, UPPER MOUNT COVE	4		
16		38157	SEAL, TRIM COVER TO DRIVE S	1		
17		38158	STRIP, RETAINING-TRIM COVER	1		
18		38154	STRIP, RETAINING-TRIM COVER	2		
19	10	48408	SCREW, RETAINING STRIP	10		
20		69543	TUBE, EXHAUST (SHORT SHAFT)	1		
20		69544	TUBE, EXHAUST (LONG SHAFT)	1		
21	32	37727	TUBE, WATER INLET (SHORT SH	1		
21	32	45679	TUBE, WATER INLET (LONG SH	1		
22	11	64809	NUT, POWERHEAD STUDS (5/16	8		
23		75304	MOUNT, RUBBER-LOWER	2		
24	10	75284	SCREW, LOWER MOUNT SCREW	2		
25	12	28051	WASHER, LOWER MOUNT SCRE	2		
26	12	28053	WASHER, RUBBER-LOWER MOL	2		
27	12	30119	WASHER, LOWER MOUNT SCRE	2		
28	11	25096	NUT, LOWER MOUNT SCREW	2		
29		69592	CLAMP, LOWER MOUNT	2		
30	10	29256	SCREW, LOWER MOUNT CLAMP	4		
31	24	35522	SPRING, TENSION-LOWER MOU	4		
32		35474	COVER, LOWER MOUNT CLAMP	2		
33	10	87884	SCREW, COVER TO LOWER MOU	2		
34	11	35521	NUT, LOWER MOUNT CLAMP CC	2		
35		88238A	WIRE ASSEMBLY, GROUND	1		
36	23	23651	SLEEVE, WATER INLET TUBE	1		