



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		76864	HOUSING, NYLON-THROTTLE A(I	1		
2		77025	CAM, NYLON-THROTTLE ACTUA	1		
3	10	37571	SCREW, HOUSING TO CRANKCA	1		
4	13	26396	LOCKWASHER, HOUSING TO CR	1		
5		60570	PLATE, RETAINER-ACTUATOR H	1		
6	23	74213	BARREL, NYLON-THROTTLE LIN	1		
7		74164	ROD, LINK-THROTTLE	1		
8		77013A 1	SWIVEL, LINK ROD TO THROTTL	1		
8A	13	29402	WAVE WASHER, LINK ROD SWIV	2		
9	23	26856	BUSHING, LINK ROD SWIVEL	2		
10	12	33786	WASHER, LINK ROD SWIVEL	2		
11	11	45774	NUT, LINK ROD SWIVEL	2		
12		77032A 2	LEVER ASSEMBLY, THROTTLE C	1		
13	10	73655	SCREW, ADJUSTING-THROTTLE	2		
14	11	29598	NUT, JAM-ADJUSTING SCREW	2		
15		52023	CAP, ADJUSTING SCREW	2		
16	10	55337	SCREW	1	THROTTLE CONTROL LEVER T	
17	23	55164	BUSHING, THROTTLE CONTROL	1		
18	23	55171	BUSHING, THROTTLE CONTROL	1		
19	24	55162	SPRING, RETURN-SPARK ADVAN	1		
20		77031A 2	LEVER ASSEMBLY, SPARK ADVAN	1		
21	12	68410	WASHER, THROTTLE CONTROL L	1		
22	10	73656	SCREW, SPARK ADVANCE ADJU	1		
23	11	68219	NUT, SPARK ADVANTAGE ADJU:	1		
24		48039	CAP, SPARK ADVANCE ADJUSTII	1		
25	10	77650	SCREW	1	ADJUSTING-SPARK ADVANCE L	
26	11	29598	NUT, JAM-ADJUSTING SCREW	1		
27		52023	CAP, ADJUSTING SCREW	1		
28		39483	LATCH	1	THROTTLE CONTROL LEVER (T	
29	10	22486	SCREW	1	LATCH TO THROTTLE CONTROL	
30	24	20099	SPRING, COMPRESSION-LATCH	1		
31	11	20586	NUT, LATCH ATTACHING SCREW	1		
32		74897	BARREL, LINK ROD TO STATOR	1		
33		74212	ROD, LINK-SPARK ADVANCE	1		
34		77013A 1	SWIVEL, LINK ROD TO SPARK AI	1		