



D-11

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		73641A 1	BRACKET, COWL SUPPORT-TOP	1		
2		62444	SEAL, RUBBER-TOP BRACKET-#	2		
3		79652	CLIP, SUPPORT BRACKET	1		
4	10	48408	SCREW, CLIP TO SUPPORT (1/2"	1		
6		79490	SHEILD, FLYWHEEL	1		
7	10	37656	SCREW, SHIELD TO SUPPORT B	1		
8	10	48409	SCREW, SHIELD TO SUPPORT B	3		
9		74510A 2	BRACKET, COWL SUPPORT-REA	1		
10		69876 1	SEAL, REAR BRACKET AND TOP	4		
11		90435	MOUNT, RUBBER-REAR SUPPO	1		
12	12	20346	WASHER, RUBBER MOUNT	2		
13	11	36069	NUT, RUBBER MOUNT	2		
14		26901	STOP, RUBBER-REAR SUPPORT	3		
15		60116	BRACE, COWL SUPPORT BRACK	1		
16	10	76596	SCREW, SUPPORT BRACKET (1-	3		
17		90435	MOUNT, RUBBER-FRONT SUPPC	1		
19	11	36069	NUT, RUBBER MOUNT	2		
20		71097	BRACKET, RUBBER MOUNT	1		
21	10	59645	SCREW, BRACKET TO CRANKCA	1		
22		88725	ATTENUATOR, SOUND	1	UNITED STATES 6104369 AND I	
22		97348	ATTENUATOR, SOUND	1	UNITED STATES 6104370 AND I	
23		88684	COVER, MANUAL CHOKE	1		
24	10	23015	SCREW, COVER TO TOP COVER	2		
25	12	53705	WASHER, COVER SCREW	1		
26		73986	AIR MANIFOLD	1		
27	10	69093	SCREW, AIR MANIFOLD	2		
28		90435	MOUNT, REBBER-FRONT SUPPC	1		
29	11	36069	NUT, RUBBER MOUNT	2		
30		76410	SEAL, FUEL CONNECTOR-SOUNI	1		
31		76578	COVER, SOUND ATTENUATOR (I	1		
32	10	37571	SCREW, FRONT COVER (1/2")	8		
33	19	73336	PLUG, FRONT COVER	2		
34		76251A 1	PLATE ASSEMBLY, FRONT COVE	1		
35		76264	LATCH, FRONT COVER	1		
36	24	60295	SPRING, FRONT COVER LATCH	1		
37	10	28635	SCRW, COVER PLATE TO SUPPC	3		
38		87764	BRACKET, REAR-LOWER MOUN	1		
39	10	76596	SCREW, REAR BRACKET ATTAC	3		
40		90435	MOUNT, RUBBER-REAR COWL E	1		
41		88238A 3	GROUND STRAP ASSEMBLY	1		
42	12	20346	WASHER, RUBBER MOUNT	2		