



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		91951	BRACKET, ANCHOR-CONTROL C	1		
2		60283A	LINK ASSEMBLY, SHIFT SHAFT	1		
3	24	20099	SPRING, LINK TO ANCHOR BRAC	1		
4		37896	GUIDE BLOCK, LINK	1		
5		52100	WEAR PLATE, NYLON-LINK	1		
6		38279	LATCH, LINK TO ANCHOR BRAC	1		
7	12	21631	WASHER, LINK LATCH	1		
8	11	36069	NUT, LINK ATTACHING	2		
9		75355A30	SHIFT SHAFT ASSEMBLY, UPPEF	1		
9		75355A32	SHIFT SHAFT ASSEMBLY, UPPEF	1		
11	13	29720	WASHER, WAVE-SHIFT SHAFT T	1		
12	23	26600	BUSHING, NYLON-SHIFT SHAFT	1		
13	12	35462	WASHER, LINK (SHIFT SHAFT EP	1		
14		39519	CUP, RETAINER-ANCHOR BRAC	1		
15		39618	LEVER, NYLON-SHIFT CABLE LO	1		
16	17	47175	PIN, LOCKING LEVER AND COVE	3		
17		65799	LINK, LOCKING LEVER TO COVE	1		
18		90211	COVER, NYLON-SHIFT CABLE	1		
19	10	69101	SCREW, ANCHOR BRACKET (7/E	3		
20	27	88451	GASKET, POWERHEAD	1		
21		88730A	EXHAUST PLATE ASSEMBLY	1	UNITED STATES 5850645 AND I	
21		93239A	EXHAUST PLATE ASSEMBLY	1	UNITED STATES 5850646 AND I	
21A	23	27132	BUSHING, NYLON-EXHAUST PI	1		
22	16	69058	STUD, EXHAUST PLATE (1-11/	1		
23	16	68166	STUD, EXHAUST PLATE (2-1/8'	1		
24	26	38452	SEAL, WATER INLET TUBE	1		6
25	12	38453	WASHER, NYLON-WATER SEA	1		
26		79799	HOUSING, WATER SEAL	1		
27	27	79797	GASKET, HOUSING	1		6
28	10	79798	SCREW, HOUSING TO EXHAUS	2		
29		60307	SEAL, EXHAUST PLATE	1		
30		60306	STRIP, RETAINING-EXHAUST F	1		
31	10	62568	SCREW, RETIANING STRIP (3/	4		
32	10	68918	SCREW, EXHAUST PLATE (1")	4		
32	10	28668	SCREW, EXHAUST PLATE (7/8")	1		
33	27	38501	GASKET, ADAPTOR PLATE	1		6
34		76903	EXHAUST TUBE, ADAPTOR	1		
35	27	60280	GASKET, EXHAUST TUBE	1		6
36	10	28636	SCREW, EXHAUST TUBE (3/4")	3		
-	27	88449A32	GASKET SET			