



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		73641A	BRACKET, COWL SUPPORT-TOP	1		
2		62444	SEAL	2	RUBBER- TOP BRACKET AND C	
3		76263	CLIP, TOP COWL SUPPORT BRA	1	UNITED STATES 4977156 AND I	
3		79652	CLIP, TOP COWL SUPPORT BRA	1	UNITED STATES 4977157 AND I	
4	10	48408	SCREW, CLIP TO TOP COWL SUI	1		
6		76580	SHIELD, FLYWHEEL	1	UNITED STATES 4977156 AND I	
6		79490	SHIELD, FLYWHEEL	1	UNITED STATES 4977157 AND I	
7	10	37656	SCREW, SHIELD TO TOP SUPPO	1		
8	10	48408	SCREW, SHIELD TO TOP SUPPO	3		
9		74510A	BRACKET, COWL SUPPORT - RE	1		
10		69876	SEAL, REAR BRACKET AND TOP	4		
11		63007	MOUNT	1	RUBBER-BRACE TO REAR TO F	
12	12	20346	WASHER	2	RUBBER MOUNT TO REAR SUF	
13	11	46887	NUT	2	RUBBER MOUNT TO REAR SUF	
14		26901	STOP, RUBBER-REAR SUPPORT	3		
15		60116	BRACE, REAR COWL SUPPORT I	1		
16	10	76596	SCREW	3	SUPPORT BRK. BRACE TO CYL.	
17		63007	MOUNT	1	RUBBER-FRONT SUPPORT BR/	
19	11	36069	NUT	2	RUBBER MOUNT TO FRONT SL	
20		71097	BRACKET, RUBBER MOUNT	1		
21	10	59645	SCREW, BRACKET TO CRANKCA	1		
22		76577	ATTENUATOR, SOUND	1	UNITED STATES 4977156 AND I	
22		79489	ATTENUATOR, SOUND	1	UNITED STATES 4977157 AND I	
23	54	28700	CLAMP, WIRES TO SOUND ATTE	1		
24	10	20031	SCREW, CLAMP SCREW	1		
27		75841	COVER, MANUAL CHOKE	1		
28	10	38055	SCREW, COVER TO TOP COVER	4		
29	12	56681	WASHSER, COVER SCREW	4		
30		73986	AIR MANIFOLD	1		
31	10	69093	SCREW, AIR MANIFOLD TO SOU	2		
34		63007	MOUNT, RUBBER-FRONT SUPPC	1		
37	11	36069	NUT, RUBBER MOUNT ATTACHI	2		
38		76410	SEAL, FUEL CONNECTOR-SOUNI	1		
39	21	77561	CONNECTOR, ATTENUATOR	1		
40	32	54936	TUBE, VENT (LOWER)	1		
41	22	71191	ELBOW, CRANKCASE VENT (PRE	1		
42		76578	COVER, SOUND ATTENUATOR (I	1		
43	27	76579	GASKET, FRONT COVER	1	UNITED STATES 5128279 AND	1,2
45	10	37571	SCREW	8	FRONT COVER TO SOUND ATT	
46	19	73336	PLUG, FRONT COVER	2		
47		76261A	PLATE ASSEMBLY, FRONT COVE	1		