



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
	1643	7406A30	GEAR HOUSING ASSEMBLY, CO	1	(SHORT SHAFT)	
	1643	7406A31	GEAR HOUSING ASSEMBLY, CO	1	(LONG SHAFT)	
1	1643	7406A16	GEAR HOUSING ASSEMBLY	1		
2	22	85822A 1	CONNECTOR ASSEMBLY, SP	1		
3	17	85500	DOWEL PIN, GEAR HOUSING	2		
4	16	33778	STUD, WATER PUMP (2-5/8")	3		
5	16	57933	STUD, GEAR HOUSING	2		
6	31	62091	ROLLER BEARING, DRIVE SH-	1		
7		72849A 1	SCREEN, WATER INTAKE-ST	1		
8	10	36070	SCREW, WATER INTAKE SCF	1		
9	11	45812	NUT, WATER INTAKE SCREE	1		
10		92815	PLATE, SUPPORT-EXHAUST TI	1		
11		37721	SEAL, EXHAUST TUBE	1		6
12	43	88019	PINION GEAR	1		
13	11	55910	NUT, PINION GEAR TO DRIVE	1		
14	27	77417	GASKET, WATER PUMP	1		6
15	25	26722	"O" RING, WATER PUMP BASE	1		6
16	46	77177A 1	WATER PUMP BASE ASSEMBL	1		
17	26	79831	OIL SEAL, WATER PUMP BAS	1		
18	26	90562	OIL SEAL, WATER PUMP BAS	1		
19	17	35973	DOWEL PIN, WATER PUMP E	2		
20	27	32769	GASKET, LOWER-WATER PUM	1		6
21		54705	PLATE, FACE-WATER PUMP	1		
22	27	32770	GASKET, UPPER-WATER PUM	1		6
23	47	89983	IMPELLER, WATER PUMP	1		
24	28	56662	KEY, IMPELLER DRIVE	1		
25	46	77822A 1	WATER PUMP BODY ASSEMBL	1		
26		48753	INSERT, WATER PUMP BOD	1		
27	26	38452	SEAL, RUBBER-WATER PUM	1		6
28	12	38453	WASHER, NYLON-WATER PL	1		
29	12	29245	WASHER, WATER PUMP STUC	3		
30	11	35888	NUT, WATER PUMP STUDS	3		
31	25	20273	RING, RUBBER (DRIVE SHAFT)	1		6
32		78654A 1	SEAT ASSEMBLY, DRIVE SHAF	1		
33		86304	SEAL, SPLINED-DRIVE SHAF	1		6
34	10	79953	SCREW, GREASE FILLER	1		
35	22	67892	SCREW, DRAIN (MAGNETIC)	1		
36	12	20260	WASHER, GREASE FILLER ANI	2		
37		88181	SLEEVE, LUBRICATION	1		
38	15	92881A 1	SHIM, ROLLER BEARING (.002-	AR		4
39	21	77420A 1	ROLLER BEARING ASSEMBLY	1		