



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	19	45907	PLUG, Yellow, Flywheel	1		
2		42956A	COVER ASSEMBLY, Flywheel	1		
3		79022	MARKER, Timing	1		
4	10	37572	SCREW, (.190-32 x .380), Timing	2		
5	12	72761	WASHER, Timing Marker Screw	2		
6	11	42979	NUT, (M16 x 1.5), Flywheel	1		
7	12	68229	WASHER, Flywheel	1		
8	261	9008A16	FLYWHEEL ASSEMBLY	1		
9	398	8778A10	STATOR ASSEMBLY, Stamped 39	1		
9	398	9710A12	STATOR ASSEMBLY, Stamped 39	1		
10	10	40073 25	SCREW, (M5 x 25), Stator	4		
11		99021A 3	TRIGGER ASSEMBLY	1		
12	50	66015	STARTER MOTOR	1		
13		56703	COLLAR, Starter Motor	2		
14		57247	STOP, Rubber, Starter Motor	2		
15	84	93388A 1	CABLE ASSEMBLY, Black, Starter	1		
16	10	69035	SCREW AND LOCKWASHER, (.25	1		
17	84	88439A20	WIRE, Starter Motor, Black	1		
18	13	26992	LOCKWASHER, (.250), Starter Mot	1		
19	11	64015	NUT, (#8-32), Starter Motor Termi	1		